## **Direct Digital Synthesis Optical Chopper**

C-995



### **Features**

- Wide Frequency Range 4 Hz to 5000 Hz
- Rock Solid Crystal Controlled Frequency
- · Large 5 Digit LED Display

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

- Frequency resolution of 0.001 Hz
- External Clock Synchronization
- · Covers 4 Hz to 5 KHz with only one blade
- Computer Interface for easy control
- Enclosed Chopper Blade

The C-995 is a microprocessor-based control system that utilizes directdigital- synthesis to deliver precise optical chopping rates from 4 Hz to 5000 Hz. Equipped with a large fi ve-digit LED readout, the C-995 controller enables digital entry of the desired chopping rates from the front panel. Additionally, the C-995 is equipped with a bi-directional Rs-232 port that permits the user to set the desired chopping rate to a resolution of .001 Hz and to read the status of the instrument.

The C-995, designed with a phase-locked-loop control system, allows the chopping rate to also be synchronized to a user-supplied external clock ranging from 4 Hz to 5 KHz. The controller is then used to measure and display the frequency of the external clock.

The C-995 chopping head is attached to the controller by means of a 10 foot coiled cord. The precision etched blade is fully enclosed for protection from inadvertent damage. (An optional exposed blade version is also available.)

There are two apertures and two sections (30 slots and 3 slots) for the high and low frequency ranges, respectively. The aperture diameter is 15 mm with a slot width of 4.5 mm (30 slot section) or 30 mm (3 slot section). The small 4.75 inch square outline and two inch maximum depth permits easy integration into compact optical setups. Dual #8-32 mounting holes permit the apertures to be placed at a height as low as 0.75 inches above an optical bench, or with the included 1/2 inch rod and stand, as high as 13 inches above the mounting surface.

The ease of use and convenience of this instrument are matched only by the high performance to price ratio that is typical of products from Terahertz Technologies Inc. The C-995 is backed by our standard two year warranty and our guarantee of customer satisfaction.

| C-995 Optical Chopper Specifications             |  |  |
|--|--|--|
| Chopping Frequency Range                         | 5 Hz to 500 Hz, (using inner set of slots),<br>40 Hz to 5 KHz (using outer set of slots) |  |
| Chopping Frequency Ranges                        | 4 Hz to 500 Hz ( Inner slots),<br>40 Hz - 5 KHz (outer slots)                            |  |
| Aperture Size                                    | 0.6 inch diameter (15 mm),<br>and 0.6 inch by 0.2 inch (15 x 4.5 mm)                     |  |
| Frequency Control                                | Phase-Locked-Loop, Direct Digital Synthesis  |  |
| Frequency Uncertainty                            | ±.0025 % of setting  |  |
| Phase Jitter                                     | 0.1 % peak to peak, 3 slot section, 1.0 % peak to peak, 30 slot section                  |  |
| Settling Time to Phase Lock                      | < 3 seconds  |  |
| External Clock Input Requirements                | TTL, CMOS Compatible Square Wave, 4 Hz to 5000 Hz  |  |
| Sync Signal Output                               | TTL, CMOS Compatible Square Wave   |  |
| Display  | Five Digit, high intensity green, 0. 5 " high  |  |
| Temperature Coefficient of Chopping Frequency    | < 10 ppm/C   |  |
| Frequency Resolution (using Rs-232 Control)      | .001 Hz  |  |
| Frequency Resolution (using Front Panel Control) | .01 Hz   |  |
| Counter Resolution using External Clock          | 0.1 Hz, 1 Hz   |  |
| Rs-232 Interface                                 | 9600 Baud, N-8-1, 3 wire   |  |
| Chopper Head Mounting                            | Standard 8-32 tapped holes, mounting rod and stand is provided                           |  |
| Chopping Blade Diameter                          | 4.1 inch diameter  |  |
| Operating Temperature Range                      | 0 - 40 C   |  |
| Dimensions (Head)                                | 4.5 " H x 4.5 " W x 2 " D, 114 mm x 114 mm x 51 mm                                       |  |
| Dimensions (Controller)                          | 2.7 " H x 7 " W x 9.1 " D, 69 mm, 178 mm, 231 mm   |  |
| Interconnecting cable supplied                   | Coiled Cord 10 feet max length   |  |
| Power Requirements                               | 95-260 VAC, 50-60 Hz, 15 VA Max  |  |
| CE Certification                                 | Yes  |  |
| Weight   | 3 lbs, 1.36 Kg   |  |
| Accessories Provided                             | Mounting rod and stand, Rs-232 cable, Power Cord, Operating Manual                       |  |
| Standard Warranty                                | Two years, Components and Workmanship, 30 Day Satisfaction Guarantee                     |  |
| Application Software Provided                    | Downloadable from TTI website, www.terahertztechnologies.com                             |  |







### **Motorized Filter Wheel**

FW-2000



#### **Features**

• 8 Position Filter Wheel

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

- · Local or Remote control
- Houses Filters 1 8 mm Thick
- Full 360 Degree Rotation
- · Windows Compatible Software
- · Easily Interchangeable Wheels

The FW-2000 is an automated or manually controlled motorized fi Iter wheel that can introduce any one of eight 25.4 mm fi Iters or transmissive windows in series with an optical path. Applications include photography, fl uorescence microscopy, and photometry.


The 104 mm fi Iter wheels are easily interchangeable and can accommodate fi Iter/window thicknesses from 1 to 8 millimeters. The clear aperture diameter is 23 mm. The aperture may be rotated continuously through 360 degrees about the motor axis in order to provide the user maximum fl exibility in a given optical setup. The unit may be controlled locally by means of two push buttons (CW, CCW) or remotely by means of the unit's USB 2.0 interface.

The current position of the wheel is indicated by a seven segment LED display. Windows™ compatible application software is provided that allows the user to determine status, command selection of any filter and also program a fi lter sequence to be followed with selectable dwell times.

The unit has numerous provisions for mounting. It may be mounted to a standard optical bench with the base provided or it may be post-mounted using a number of standard threaded posts (8-32, M-3, 1/4-20 or M6).

Operating power is supplied by a wall mount supply that automatically accommodates line voltages of 95 to 260 VAC, 50-60 Hz. Four mains adaptors are supplied to accommodate North American, Continental Europe, British and Australian standards.

| FW-2000 Specifications      |   |  |
|-----------------------------|---|--|
| Filter Accepted             | Up to eight 1" Dia. windows or fi Iters   |  |
| Filter Settling Time        | < 0.25 sec. to adjacent location, < 0.62 sec. to move 4 locations                         |  |
| Aperture Placement          | May be rotated 360° about the units axis, may be as close as 42 mm above mounting surface |  |
| Display and Controls        | 7 segment green LED display of position, CW and CCW buttons                               |  |
| Computer Interface          | USB 2.0   |  |
| Power Requirements          | <10vA, 95-260VAC, 50-60Hz   |  |
| Mounting                    | Thru hole plate for optical bench plus 1/4-20, 8-32, M4 and M6 threaded holes             |  |
| Mains Connectors Supplied   | North America, Continental Europe, Great Britain and Australia                            |  |
| Dimensions (mm)             | 4.8" Dia., 5.5"H, wheel house 0.75" thick   |  |
| Weight                      | 1.5 lbs.  |  |
| Operating Temperature Range | 0-40C   |  |
| Accessories Supplied        | Usb Cable, wall mount power supply, 8 retaining rings, manual and application software    |  |



鼎昕科技

## HyperTest Advanced Fiber

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

### **Optic Loss Test Set**

**HPT-5100** 



#### **Features**

- Real time display of Dual Wavelength Loss and ORL
- Automated dual wavelength loss and ORL measurements
- · Bi-directional measurements using a single fi ber
- Built in fi ber identifi er
- Text Messaging Communications
- Computer and Printer interface
- Q VGA Graphic Display
- Display Backlighting
- Rugged, Watertight Case
- Storage for 1000 records
- Free PC application software
- Rechargeable NiMH batteries , 16 Hours / charge

The HPT-5100 Advanced Fiber Optic loss Test Set represents a significant improvement in technology at a competitive price. This high performance loss test set has advanced features commonly found in instruments costing far more.

As a true bi-directional loss test set it proves real-time (updated four times per second) measurements of Loss and Optical Return Loss of a single fi ber in both directions at wavelengths of 1310 and 1550 nm.


When used as a Power Meter it measures optical signals over a dynamic range of 25 to - 60 dBm. Six calibrated wavelengths are provided. DB reference levels may be stored at each calibrated wavelength.

To maximize measurement productivity, text messaging is provided between the master and slave units. This allows quick and reliable communication between workers at each end of the fi ber installation. The unit's Fiber Identification capability is useful for locating one of a number of fi bers for measurement.

Up to 1000 records may be stored for later downloading to a computer for purposes of system documentation.

With its large four inch diagonal backlit graphic display, rugged casework and ease of use, the HPT-5100 is the perfect tool for the installation, characterization and maintenance of fi ber optic systems

| НР  | T-5100 Specifications  |
|---|--|
| Loss Measurement Dynamic Range                      | 0 - 45 dB in Hypertest Mode, 60 dB in Manual Mode                              |
| Loss Measurement Wavelengths                        | 1310, 1550 nm, ± 20 nm   |
| Laser Output Power 0                                | dBm, 1 mw  |
| Units of Measurement                                | dBm, dB, 0.01 dB resolution  |
| Measurement Rate                                    | Four updates per second  |
| Inter-unit Communications                           | Text, eight standard messages provided,<br>Transmitted via Fiber-Under-Test    |
| Hypertest Displayed Quantities                      | Loss A-B, Loss B-A, ORL from A, ORL from B, Each value @ 1310 and 1550 nm      |
| Laser Safety Classification.                        | Class I safety per FDA/CDRH and IEC-825-1 regulations                          |
| Laser Output Power                                  | 0 dBm, 1 mw  |
| Laser Output Stability                              | ± 0.1 dB for 1 hour  |
| Laser Linewidth                                     | < 5 nm   |
| Optical Return Loss Dynamic Range                   | 0 - 65 dB  |
| Optical Return Loss Accuracy                        | ± 0.5 dB @ a -55 dB reflection   |
| Power Meter Detector                                | InGaAs, 2 mm diameter with universal 2.5 mm ferrule adaptor                    |
| Calibrated Wavelengths Provided                     | 850, 1300, 1310, 1490, 1550, 1625 nm   |
| Modulation Modes Provided,<br>(transmit and detect) | CW, 270 Hz, 1000 Hz, 2000 Hz   |
| Power Meter Accuracy                                | ± 0.18 dB under reference conditions,<br>± 0.3 dB +20 to - 50 dBm              |
| Power Meter Display                                 | .01 dB resolution, unit of dBm or dB   |
| Memory Storage Locations                            | 1000   |
| Display   | 4 " QVGA LCD Graphic Display with Electroluminescent Back light                |
| Standard Optical Connector Interface                | FC/APC, (other types available or request)                                     |
| Batteries Supplied                                  | Rechargeable NiMH AA cells, eight  |
| Operating Time                                      | Approximately 16 hours following a full charge                                 |
| Power Supply / Charger Provided                     | Wall Mount, 120 VAC, 50 -60 Hz, or 220 VAC 50-60 Hz, Specify                   |
| Power Requirements                                  | 10 VA Max  |
| Temperature Range                                   | 0 to 50 C Operating,, -20 to 60 C Storage                                      |
| Dimensions (L x W x D)                              | 8.1" x 6.4" x 3.5", 210 x 160 x 90 mm  |
| Weight  | 2.8 lbs, 1.3 Kg  |
| Accessories Provided                                | Batteries, Power supply/charger, manual, Rs-232 Cable, PC application software |
| Standard Warranty                                   | Two years, Components and Workmanship,<br>30 Day Satisfaction Guarantee        |
|   |  |







Power Meter Mode

Fiber Optic

### Fiber Optic Laser Tachometer

LT-880



#### **Features**

- Remote Sensing of RPM and Angular Vibration
- No Special Refl ective Tape Required
- Large 5 Digit LED DisplaySensing rates to 40 000 PPS
- Ni-mH Powered with Fast Charger
- Measures RPM, RPS, PPS
- Entry of number of encoder sectors

The LT-880 Laser Tachometer is a hand-held, battery operated device that senses the passage of reflective/ non-reflective markings on a rotating or linearly translated piece of machinery in order to determine the target's rotational rate or its linear velocity. The sensing head is remote from the electronics package and is fi ber coupled. This permits measurement of objects in hostile environments or in hard-to-get-to locations. The sensed change in reflectivity from black to white generates a transition at its output. This TTL/CMOS compatible signal may be utilized by a spectrum analyzer, computer or electronic counter in order to provide information concerning vibration, angular or linear velocity of the machinery under test. The high speed of the unit, 40, 000 PPS, coupled with its small spot size can provide high resolution measurements unattainable with conventional incandescent source tachometers.

A six digit LCD display indicates the rate of passage of the white/dark areas of the encoder and registers the results in units of revolutions per minute, (RPM), revolutions per second, (RPS), or pulses per second (PPS). The reading is updated twice per second. The user may input the number of pulses per revolution of the encoder for use in the subsequent calculations. They may range from 1 pulse per revolution to 255 pulses per revolution.

| Sensor Head |           |
|-------------|-----------|
| Dupl        | ex Fibers |

| LT-880 Laser Tachometer Specifications          |  |
|---|--|
| Units of Measurement                            | Revolutions per Second, Revolutions per Minute, Pulses per Second    |
| Measurement Update Rate                         | Twice per Second   |
| Readout Uncertainty                             | ±02 % of Reading, ±. 1 LSD   |
| Maximum Measurement Rate                        | 40 000 PPS   |
| Range from Sensor to Target                     | 12 to 125 mm (using white copier paper)                              |
| Laser Wavelength                                | 650 nm ±.10 nm   |
| Laser Output Power                              | < 2 milliwatts   |
| Laser Spot Size                                 | < 1.9 mm @ 13 mm range   |
| Laser Beam Divergence                           | < 13 milliradians  |
| Display   | Six Digit LCD, 0.375 height, Six LED annunciators                    |
| Frequency Output Port                           | TTL pulse for each reflective sector sensed, (0 to 5 volts)          |
| Output Impedance                                | 100 Ohms   |
| Standard Fiber Optic Cable Length               | 5 meters   |
| Standard Fiber Types                            | Receiver - 400 u m core, Transmitter - 62.5 um core                  |
| Standard Connector Type                         | ST Type  |
| Batteries Supplied                              | Four AA NimH, 2500 ma-H  |
| Charger Power Requirements                      | 95 - 260 VAC, 50-60 Hz Universal, < 10 VA                            |
| Mains Connectors Supplied                       | North American, Great Britain, Continental Europe, Australian        |
| Charging Time                                   | Approximately two hours  |
| Dimensions (Controller)                         | 200 mm L x 98 mm W x 38 mm D   |
| Dimensions (Sensor)                             | 36 mm K x 13 mm Diameter, 1/2 by 20 Thread, Jam Nuts Included        |
| Operating Temperature, Electronics, Sensor Head | 0 - 50 C, - 40 - 120 C   |
| Weight  | 0.6 Kg   |
| Accessories Provided                            | Carrying Case, Batteries, Power Supply/Charger, Operating Manual     |
| Standard Warranty                               | Two years, Components and Workmanship, 30 Day Satisfaction Guarantee |

# **Automated Fiber Optic Loss Test Set**

LTS-1500



#### **Features**

- · Automated loss measurements for three wavelengths
- · Auto wavelength switching
- Universal Power Meter and Light Source adapters FC/ST and SC
- Power Meter with -75 dBm Dynamic Range
- Single port laser source with up to three wavelengths
- Storage for 2000 triple wavelength loss measurements
- Rechargeable Li polymer 9V battery
- USB interface
- Free Windows® compatible report software
- Reference level storage

The LTS-1500 is a small, rugged automated fi ber optic loss test set that characterizes singlemode and multimode fi ber links at wavelengths of 850,1300, 1310, 1490 and 1550 nm, It is comprised of a sensitive InGaAs based optical power meter calibrated at six wavelengths with better than -75 dBm noise level plus a stabilized laser light source with up to three selectable wavelengths.

In the Autotest mode, the master unit changes wavelengths at a fi xed rate and informs the slave unit of the wavelength currently being measured. Storing the loss measurement saves the loss at each wavelength in memory. Up to 2000 triple wavelength measurements may be stored and recalled via the unit's USB port or from the front panel. PC application software is provided for downloading stored data and organizing the information.

The units also performs fi ber identifi cation functions with modulation frequencies of 270, 1000 and 2000 Hz.

Power is obtained from a rechargeable lithium polymer battery that provides more than 15 hours of continuous operation, its universal power supply, or in a pinch, any common 9V alkaline battery.

Standard accessories include a protective rubber boot and stand, USB cable, adaptors for FC, ST or SC connectors, universal power supply/charger, CD containing application software and an operating instruction booklet.

| LTS-1500 Specifications        |  |  |
|--------------------------------|--|--|
| Power Meter Detector Type      | InGaAs   |  |
| Dynamic Range                  | +5 to -77 dB   |  |
| Calibrated Wavelengths         | 850, 1300, 1310, 1490, 1550, 1625 nm   |  |
| Units of Measurement           | dBm, dB,   |  |
| Resolution                     | 0.01dB   |  |
| Power Input Range              | +5 dBm to - 77 dBm   |  |
| Power Measurement Uncertainty  | $\pm$ 0.18 dB under reference conditions, $\pm$ 0.25 dB from 0 to -65 dBm, $\pm$ 0.35 dB from 0 to +5 dBm and from -65 to -77 dBm                        |  |
| Laser Output Power             | 0 dBm, 1mw   |  |
| Output Stability               | ± .05 dB / 24 hrs @ constant temp,<br>± .02 dB/C temperature coeffi cient  |  |
| Laser Wavelengths Provided     | 850nm, 1300nm, 1310 nm , 1490, 1550 (± 20 nm)  |  |
| Modulation Modes               | CW, 270 Hz, 1000 Hz, 2000 Hz   |  |
| Laser Safety Classification    | Class I safety per FDA/CDRH and IEC-825-1 regulation   |  |
| Autotest Range                 | 0 to - 36 dB   |  |
| Display                        | LCD, power reading, 0.4" high digits, .01 dB resolution Power meter, laser wavelength display 0.16" high digits  |  |
| Annunciators                   | Fiber ID, - 3, modulation mode - 4, Autotest - 2, Lo Bat, Auto Off   |  |
| Storage Locations              | 2000   |  |
| Battery/Operating Time         | Rechargeable Li Polymer/Approximately fi fteen hours following a full charge   |  |
| Power Supply / Charger         | Universal, US, UK, Continental Europe, and Australian Plugs Included   |  |
| Power Requirements             | 95-260 VAC, 50-60 Hz, 3 VA Max   |  |
| Operating Temperature Range    | -10 to 45 C  |  |
| Dimensions (with rubber boot ) | 5.9" L x 3.9" W x 1.37" H (150mm L x 100mm W x 35mm H)   |  |
| Weight                         | 0.52 Kg  |  |
| Accessories Provided           | FC, ST, SC adaptors for both<br>Power Meter and Light Source, rubber boot, battery, Power supply/<br>Charger, manual, USB Cable, PC application software |  |

| LTS-1500 Ordering Information |  |
|-------------------------------|--|
| LTS-1500-813                  | Loss Test Set with 850/1300nm Light Source       |
| LTS-1500-3                    | Loss Test Set with 1310nm Light Source           |
| LTS-1500-5                    | Loss Test Set with 1550nm Light Source           |
| LTS-1500-35                   | Loss Test Set with 1310/1550nm Light Source      |
| LTS-1500-345                  | Loss Test Set with 1310/1490/1550nm Light Source |

Fiber Optic

### **Electrical to Optical** Converter

LTX-510



#### **Features**

- Two Voltage Input Ranges
- Two Impedance Settings
- Transmit without conducting
- Bandwidth to >60MHz (-3dB)

The LTX-510 Electrical to Optical Converter is a convenient device that is intended to transmit analog or digital signals to a remote location via a multi-mode fi ber optic cable. The primary applications are those situations in which the signal of interest has a high common mode voltage with respect to the measurement equipment. These applications include plasma physics experiments, power transmission equipment, and high power laser equipment. Trigger information from electrically noisy sources such as high current discharge laser systems may be transmitted without conducting Electro-Magnetic Interference, (EMI), to the measurement equipment.

The LTX-510 is intended for use with the TIA-525S Optical to Electrical Converter but can be used with other o/e converters that respond at 850 nm and have the appropriate responsivity and bandwidth. The input impedance may be set to 50 ohms for high speed signals sent over a transmission line or to 1 Megohm for use at lower frequencies. The input connector is a female BNC and the output connector is a ST style.

| LTX-510 Specifications |   |  |
|------------------------|---|--|
| Input Voltage Range    | 0 to + 1 V or 0 to + 5 V, selectable                          |  |
| Input Impedance        | 50 ohms or 1 Megohm in parallel with 20 pF                    |  |
| <b>Output Power</b>    | 10 microwatts, - 20 dBm Typical                               |  |
| Input Without Damage   | +/- 7 V   |  |
| Bandwidth (- 3 dB)     | DC to 60 MHz  |  |
| Accuracy               | +/- 5% from DC to 35 MHz, +/- 20% from DC to 50 MHz           |  |
| Output Wavelength      | 850 nm, 100 nm FWHM   |  |
| Input Connector        | BNC Female  |  |
| Fiber Output Connector | ST  |  |
| Usable Fiber Type      | Multi-mode, 62.5/125 or 100/140                               |  |
| Power requirements     | 12 +/- 0.5 VDC@ 100mA or 120 VAC with wall-mount power supply |  |
| Dimensions             | 4.5"W, 2.5"L, 1.0"H (114,63,25mm)                             |  |
| Weight                 | 8 oz., 230 g  |  |
| Operating temperature  | 10 - 40 C   |  |
| Limited warranty       | 2 years from date of receipt                                  |  |

### **Analog/Digital Bidirectional Fiber Optic Link**

LTX721X

#### **Features**

- Single Fiber Transceivers
- DC-25MHz Analog
- · Four Independent Digital Channels
- 0 to 48Mb/s per Digital Channel
- +/-5V or +/-1V Full Scale I/O
- · Digital LVTTL, CMOS/TTL Input
- Analog I/O 12 bit Precision
- AC/DC Operation




Transmit and receive precise analog data from DC to 25 Mhz over a single optical fiber!

The LTX-721X Bidirectional Fiber Optic Links multiplex one analog signal along with up to 4 independent TTL/CMOS/LVTTL digital channels to over 10 kilometers with a single fi ber. The incoming analog data is digitized to 12 bit precision at up to 100 mega samples per second and the digital channels operate at data rates of 0 to 50Mb/s. This is then transmitted at speeds up to 2 Gb/s second for distances up to 10 kilometers. The digital signal is then received and the analog signal is accurately reproduced at the far end of the fi ber optic link.

Depending on the model the analog signal bandwidth may be from DC to 25 MHz (-3dB). The LTX- 721X has input voltage ranges of ±1 Volt or ±5 Volts. The input impedance of the analog channel may be set to 50 ohms or 1 megohm (75 ohms is optional)

The LTX721X series has a battery option that will allow for up to 4 hours of operation for experiments at extremely high potentials.



#### **Specifications**

|   | LTX-7210 Standard Speed     | LTX-7215 High Speed |
|---|-----------------------------|---------------------|
| Number of Digital Channels                | 4                           |                     |
| Digital Inputs                            | TTL, LVTTL, CMOS compatible |                     |
| Digital Outputs                           | LVTTL ( 0 - 3.3 V)          |                     |
| Signal Latency (with one meter of fi ber) | Approximately 300 ns        |                     |
| Digital switching Rates                   | 0 - 12.5 MHz                | 0 - 25 MHz          |
| Digital Signal Edge Uncertainty           | 0 - 10 ns                   |                     |

| Analog Channels           | LTX-7210 Standard Speed   | LTX-7215 High Speed  |
|---------------------------|---|----------------------|
| Number of Analog Channels |   | 1                    |
| Analog Signal Bandwidth   | DC to 12.5MHz (-3 dB)   | DC to 25MHz (-3 dB)  |
| Resolution                | 12 Bits   |                      |
| Input Voltage Ranges      | +/- 1 V or +/- 5 V  |                      |
| Transfer Accuracy         | +/- 10 mV offset, +/- 0.1% Full Scale(100Hz sine wave 8v pk-pk) |                      |
| Output Impedance          | 50 Ohms   |                      |
| Output Drive Capability   | +/- 5 V open circuit, +/- 2 V into 50 ohm load                  |                      |
| Input Impedance           | 50 Ohms or 1 Megohm    20 pF, (selectable)                      |                      |
| A/D Sampling Rate         | 50 Mega samples p/s   | 100 Mega samples p/s |

| General                               | LTX-7210 Standard Speed   | LTX-7215 High Speed                     |
|---------------------------------------|---|---|
| Laser Wavelength                      | LTX-5515-850; 850 nm+/- 20 nm, L  | -TX-5515-1310; 1310 nm +/- 20 nm        |
| Optical Transmission Rate             | 1.0 Gb/S  | 2.0 Gb/S                                |
| Loss Budget                           | 7   | dB                                      |
| Laser Safety                          | Classification Class I safety per FD  | A/CDRH and IEC-825-1 regulations        |
| <b>Typical Transmission Distances</b> | 10 KM with 9/125 micron fi ber  |   |
| Fiber Optic Connectors                | ST standard, FC available upon request  |   |
| Analog Connector                      | BNC   |   |
| Digital Connector                     | (Cable and Breakout Board Supplied)   |   |
| <b>LED Annunciators Provided</b>      | Input Overload ( transmitter ), Optical Signal and Power ( receiver )           |   |
| Power Supplies                        | Wall Mount, Universal, US, UK, Continental Europe and Australian plugs included |   |
| Power Requirements                    | 95 - 260 VAC, 50 - 60 Hz, 16 VA Max.  |   |
| Batteries/hrs of Operation            | 6 AA NiMH / 4 hrs   | 6 AA NiMH / 3 hrs                       |
| <b>Operating Temperature Range</b>    | 0 - 40 C  |   |
| Transmitter Dimensions ( mm )         | 214 L x 114 W x 59 H  |   |
| Weight (each)                         | 0.578 Kg  |   |
| Standard Warranty                     | ·   | nts and Workmanship,<br>ction Guarantee |

|                   | Ordering Information   |
|-------------------|--|
| LTX-7210-1310     | Singlemode, 1.0 Gb/s Analog/Digital Signal Transporter                   |
| LTX-7215-1310     | Singlemode, 2.0 Gb/s Analog/Digital Signal Transporter                   |
| LTX-7210-1310-BAT | Singlemode, 1.0 Gb/s Analog/Digital Signal Transporter with Battery Pack |
| LTX-7215-1310-BAT | Singlemode, 2.0 Gb/s Analog/Digital Signal Transporter with Battery Pack |

### **Bidirectional Fiber Optic Link**

LTX722X



Pair a LTX-722X with a LTX-721X to confi gure remote high speed 12 bit A/D and D/A converter links


#### **Features**

- · Single Fiber Transceivers
- Transmits 16 independent Channels
- 0 to 25 Mb/s Bandwidth
- 1310nm for Links to 10km
- Digital LVTTL, CMOS/TTL Input
- Outputs are LVTTL (0-3.3V)
- AC/DC Operation

The LTX-722X Bidirectional Fiber Optic Links multiplex up to 16 independent channels of digital TTL/ CMOS/LVTTL information to over 10 kilometers with Singlemode fi ber. The LTX- 722X samples each of the channels up to 100 million times a second, The signals are then multiplexed and transmitted serially over a single optical fi ber at up to 2 gigabits per second. The far end of the fi ber link demultiplexes the signal back into independent outputs. Each of these channels maybe be toggled at rates up to 50 Mb/s.

Using the LTX-721X in conjunction with a LTX-722X unit, the result is a remote fi ber-coupled 12- bit data acquisition system, digitizing the signal at 50 Mb/s and reconstructs the signal by means of a fast D/A converter. The units may also be employed in the reverse direction if desired.

Applications include data acquisition for plasma physics experiments, signal transmission and control of equipment at high voltage potentials, operations through Faraday shields, and precise noise -free signal transmission in hostile EMI environments.



### **Specifications**

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

| Digital Channels                             | LTX-7220 Standard Speed   | LTX-7225 High Speed |
|--|---|---------------------|
| Number of Digital Channels                   | 16  |                     |
| Digital Inputs                               | TTL, LVTTL, CM  | OS compatible       |
| Digital Outputs                              | LVTTL ( 0   | - 3.3 V)            |
| Signal Latency<br>(with one meter of fi ber) | Approximate   | ely 300 ns          |
| Digital switching Rates                      | 0 - 12.5 MHz  | 0 - 25 MHz          |
| Digital Signal Edge Uncertainty              | 0 - 10  | ) ns                |
| Laser Wavelength                             | 1310 nm +   | ·/- 20 nm           |
| Optical Transmission Rate                    | 1.0 Gb/S  | 2.0 Gb/S            |
| Loss Budget                                  | 7 dB  |                     |
| Laser Safety Classification                  | Class I safety per FDA/CDRH and IEC-825-1 regulations                           |                     |
| Typical Transmission Distances               | 10 KM with 9/125 micron fi ber  |                     |
| Fiber Optic Connectors                       | ST standard, FC available upon request  |                     |
| Analog Connector                             | BNC   |                     |
| Digital Connector                            | HDMI (Cable and Breakout Board Supplied)  |                     |
| LED Annunciators Provided                    | Input Overload ( transmitter ), Optical Signal and Power ( receiver             |                     |
| Power Supplies                               | Wall Mount, Universal, US, UK, Continental Europe and Australian plugs included |                     |
| Power Requirements                           | 95 - 260 VAC, 50 - 60 Hz, 16 VA Max.  |                     |
| Batteries/hrs of Operation                   | 6 AA NiMH / 4 hrs 6 AA NiMH / 3 hrs   |                     |
| Operating Temperature Range                  | 0 - 40 C  |                     |
| Transmitter Dimensions ( mm )                | 214 L x 114 W x 59 H  |                     |
| Weight (each)                                | 0.578 Kg  |                     |
| Standard Warranty                            | Two Years, Components and Workmanship, 30 day Satisfaction Guarantee            |                     |


|                   | Ordering Information   |
|-------------------|--|
| LTX-7220-1310     | Singlemode, 1.0 Gb/s 16 Channel Digital Signal Transporter                   |
| LTX-7225-1310     | Singlemode, 2.0 Gb/s 16 Channel Digital Signal Transporter                   |
| LTX-7225-1310-BAT | Singlemode, 1.0 Gb/s 16 Channel Digital Signal Transporter with Battery Pack |
| LTX-7225-1310-BAT | Singlemode, 2.0 Gb/s 16 Channel Digital Signal Transporter with Battery Pack |


### **Optical to Electrical Converter**

The TIA-525, 527 and 952 series have BNC outputs for direct connection to your oscilloscope or digitizer. The TIA-1200, 2000, 3000, and 4000 use a type K SMA female output connector. Free space options are available. Patch cords and adapters can be supplied to mate with various fi ber optic connectors. The TIA-525 and 527 have dual power capability, battery and external universal power supply.

#### **Features**

- 400 nm to 1700 nm wavelengths
- Battery or External AC Operation
- Bandwidth to 20 GHz
- Compact Size





TIA-4000





| Model/BW                                 | Detector          | Wavelength    | Power                                       | AC/DC Coupling    | Conversion Gain @ Peak Wavelength |
|--|-------------------|---------------|---|-------------------|-----------------------------------|
| TIA-525S-ST<br>(125 MHz)                 | Silicon           | 400 -1000 nm  | 9 V Lithium Battery*/<br>Univ. Power Supply | Selectable        | 100,000 V/W                       |
| TIA-525I-FC or -ST<br>(125 MHz)          | InGaAs            | 850 - 1700 nm | 9 V Lithium Battery*/<br>Univ. Power Supply | Selectable        | 100,000 V/W                       |
| TIA-527-FC<br>(125 MHz)                  | Matched<br>InGaAs | 850 - 1700 nm | 9 V Lithium Battery*/<br>Univ. Power        | Supply Selectable | 100,000 V/W                       |
| TIA-952-FC<br>(750 MHz)                  | InGaAs            | 900 - 1700 nm | Universal Power                             | Supply            | AC 2500 V/W                       |
| TIA-1200-FC<br>(12 GHz Typ.)             | InGaAs            | 900 - 1700 nm | Universal Power                             | Supply            | DC 0.8 A/W                        |
| TIA-2000-FC<br>(20 GHz Typ.)             | InGaAs            | 1260 -1620 nm | Universal Power                             | Supply            | DC 0.8 A/W                        |
| TIA-3000<br>(11 GHz Typ.)                | InGaAs            | 900 - 1700 nm | Universal Power                             | Supply            | AC 500 V/W                        |
| TIA-4000-FC<br>(30KHz -7 GHz )           | InGaAs            | APD           | 950 - 1650 nm<br>Universal Power            | Supply            | AC 2500 V/W                       |
| See reverse side for full specifications |                   |               |   |                   |                                   |

\*30 hrs avg. (no load) 9 V Lithium, use of std 9 Volt battery will provide approx. 1/3 life of Lithium battery.

Specifi cations subject to change without notice

#### **O/E Converter Selection Chart**

|                              | TIA-525  | TIA-527  | TIA-952   |
|------------------------------|--|--|---|
| Detector Types               | Silicon(400-1000nm)<br>InGaAs (850 -1700nm)                                      | Matched InGaAs<br>InGaAs (850 -1700nm)   | InGaAs (850-1700nm)                                     |
| Transimpedance Ranges        | 1.4 K,14 K   | 1.4 K,14 K   | 1.2 k   |
| Current Responsivity         | N/A  | N/A  | N/A   |
| Post Amplifi er Gain         | 1.0, 10.0 selectable   | 1.0, 10.0 selectable   | 1.0, 5.0 selectable                                     |
| Max. Linear Input Power      | 1.2 mW   | 1.2 mW   | 2 mW  |
| Max. Input w/o Damage        | 10 mW  | 10 mW  | 15 mW   |
| Bandwidth (-3 dB)<br>50 Ohms | DC - 125 MHz gain 1.0<br>DC - 35 MHz gain 10<br>12GHz (min.)<br>14 GHz (typical) | DC - 125 MHz gain 1.0<br>DC - 35 MHz gain 10<br>12GHz (min.)<br>14 GHz (typical) | 30KHz - 800 MHz<br>Gain 1.0 30Khz - 300 MHz<br>Gain 5.0 |
| Output Impedance             | 50 Ohms  | 50 Ohms  | 50 Ohms   |
| Output Connector             | Male BNC   | Male BNC   | Male BNC  |
| F. O. Input Connector        | ST, FC or Free-Space   | FC   | FC or ST  |
| Input Numeric Aperture       | 0.295  | 0.295  | 0.29  |
| Inter-Stage Coupling         | AC or DC selectable  | AC or DC selectable  | AC  |
| Output Offset Voltage        | +/1 V at Max Gain  | +/1 V at Max Gain  | N/A   |
| Max Output Voltage           | 4 V pk-pk, no load,<br>2 V pk-pk 50 ohm load                                     | 4 V pk-pk, no load,<br>2 V pk-pk 50 ohm load                                     | 2 V pk-pk 50 ohm load                                   |
| Noise Level                  | 3 pW/Hz <sup>1/2</sup>   | 3.6 pW/Hz <sup>1/2</sup>   | 9.5 pW/Hz <sup>1/2</sup>                                |
| Power Required               | 9 V Lithium Battery or Univ. Power Supply  | 9 V Lithium Battery or Univ. Power Supply  | Universal Power Supply                                  |
| Dimensions                   | 1.2W, 2.5L, 1.5H inches<br>30.5W, 63L, 39H mm                                    | 1.2W, 2.5L, 1.5H inches<br>30.5W, 63L, 39H mm39<br>mm H                          | 1.2W, 2.5L, 1.5H inches<br>30.5W, 63L, 39H mm           |
| Weight                       | 5.6 oz, 160 g  | 5.6 oz, 160 g  | 5.6 oz, 160 g   |
| Operating Temperature        | 0 to 40 C  | 0 to 40 C  | 0 to 40 C   |
| Limited Warranty             | 2 yrs from date of receipt   | 2 yrs from date of receipt   | 2 yrs from date of receipt                              |

### O/E Converter Selection Chart

| TIA-1200  | TIA-2000  | TIA-3000   | TIA-4000                                     |
|---|---|--|--|
| InGaAs (900 -1700nm)                            | InGaAs/InP (1260-<br>1620nm)                    | InGaAs (900 -1700nm)                                       | InGaAs (950 -1650nm)                         |
| 50 Ohm internal in parallel, user supplied load | 50 Ohm internal in parallel, user supplied load | V <sub>R</sub> = 500 V/W                                   | R <sub>v</sub> = 2500 V/W                    |
| 0.8 A./W @ 1550nm Typ.                          | 0.8 A./W @ 1550nm Typ.                          | N/A  | N/A  |
| Not amplifi ed                                  | Not amplified                                   | NA   | NA   |
| 3 mW  | 3 mW  | 2 mW   | 1.0 mW Max.                                  |
| 10 mW   | 10 mW   | 3 mW   | 5 mW   |
| DC to 14GHz Typ,<br>12 GHz Minimum              | DC to 20GHz Typ,<br>18 GHz Minimum              | 100 KHz to<br>8.5 GHz (min.)<br>100 Khz to<br>11 GHz (typ) | 30 KHz to 7 GHz (typ)                        |
| 50 Ohms   | 50 Ohms   | 50 Ohms  | 50 Ohms                                      |
| SMA Type K Female                               | SMA Type K Female                               | SMA Type K Female  | SMA Type K Female                            |
| FC or FC/APC                                    | FC/UPC or FC/APC                                | FC or FC/APC   | FC/APC                                       |
| 0.11 9 µm Singlemode                            | 0.11 9 µm Singlemode                            | 0.11 9 µm Singlemode                                       | 0.11 9 µm SinglemodeFC o                     |
| DC  | DC  | AC   | AC   |
| 0   | 0   | NA   | NA   |
| 0.1 V   | 0.1 V   | 0.65 V into 50 Ohms  | 0.65 V into 50 Ohms                          |
| Dark Current <1.0 nA                            | Dark Current <1.0 nA                            | 15pW/Hz <sup>1/2</sup>                                     | 16pW/Hz <sup>1/2</sup>                       |
| Univ. Power Supply                              | Univ. Power Supply                              | Universal Power Supply                                     | Universal Power Supply                       |
| 1.2W, 2.5L, 1.5H inches<br>30.5W, 63L, 39H mm   | 1.2W, 2.5L, 1.5H inches<br>30.5W, 63L, 39H mm   | 1.2W, 2.5L, 1.5H inches<br>30.5W, 63L, 39H mm              | 2.5W, 4.0L, 1.2H inches<br>63W, 102L, 31H mm |
| 5 oz, 150 g                                     | 5 oz, 150 g                                     | 5 oz, 150 g  | 5 oz, 150 g                                  |
| 0 to 40 C                                       | 0 to 40 C                                       | 0 to 40 C  | 0 to 40 C                                    |
| 2 yrs from date of receipt                      | 2 yrs from date of receipt                      | 2 yrs from date of receipt                                 | 2 yrs from date of receipt                   |

Specifi cations subject to change without notice


Fiber Optic Product

3 - 61

60

## "Signal Transporter" E/O - O/E Converter pair

LTX-5510



#### **Features**

- One analog plus four digital channels
- DC to 12.5 MHz analog bandwidth
- Input ranges of ± 1 V and ± 5 V
- Analog signal digitized to 12 bit precision
- Four independent digital (TTL) channels
- DC to 24 Mb/s data rate (each channel)





The LTX-5510 enables the precise conveyance of one analog channel plus four digital channels of information over fi ber optic links ranging from meters to more than 10 kilometers.

Incoming analog data is digitized to 12-bit precision at 50 megasamples per second and transmitted over optical fi ber at one giga-bit per second. The receiver acquires this digital data and accurately reconstructs the analog signal at the far end of the fi ber optic link.

The analog signal bandwidth is from DC to 12.5 MHz (-3 dB).

Two input voltage ranges are provided, ± 1 Volt and ± 5 Volts. The input impedance of the transmitter analog channel may be set to 50 ohms or 1 megohm (75 ohms is optional).

Multiplexed along with the analog data, are four independent TTL/CMOS/LVTTL digital signals that may be toggled at rates of up to 24 Mb/s.

Two models are available. Selection depends on the fi ber type and the length of the fi ber optic link that is required. The LTX-5510- 850 transmits at 850 nm over multi-mode fi ber optic links of up to 500 meters in length, while the LTX-5510-1310 transmits at 1310 nm over single-mode fi ber to span distances exceeding

Applications include data acquisition for plasma physics experiments, signal transmission and control of equipment at high voltage potentials, transmission of high quality video, and precise noise-free signal transmission in hostile EMI environments.

| LTX-                                      | 5510 Specifications  |
|---|--|
| Analog Signal Bandwidth                   | DC to 12.5 MHz (-3 dB)   |
| Input Voltage Ranges                      | +/- 1 V or +/- 5 V (selectable)  |
| Resolution                                | 12 Bits  |
| Transfer Accuracy                         | +/- 0.1% Full Scale, +/- 20 mV offset  |
| Signal Latency (with one meter of fi ber) | Approximately 300 nS   |
| A/D Sampling Rate                         | 50 Megasamples per second  |
| Input Impedance                           | 50 Ohms or 1 Megohm    20 pF, (selectable)   |
| Output Drive Capability                   | +/- 5 V open circuit, +/- 2 V into 50 ohm load                                     |
| Output Impedance                          | 50 Ohms  |
| Digital Inputs                            | TTL, LVTTL, CMOS compatible  |
| Digital Outputs                           | LVTTL ( 0 - 3.3 V)   |
| Digital switching Rates                   | 0 - 12 MHz   |
| Digital Signal Edge Uncertainty           | 0 - 20 nS  |
| Laser Wavelength                          | LTX-5510-850; 850 nm+/- 20 nm, LTX-5510-1310; 1310 nm +/- 20 nm                    |
| Optical Transmission Rate                 | 1.0 Gb/S   |
| Loss Budget                               | 15 dB max.   |
| Optical Return Loss                       | > 15 dB  |
| Laser Safety Classification               | Class I safety per FDA/CDRH and IEC-825-1 regulations                              |
| Typical Transmission Distances (850 nm)   | 500 M with 50/125 micron fi ber,<br>300 M with 62.5/125 micron fi ber              |
| Typical Transmission Distances (1310 nm)  | 10 KM with 9/125 micron fi ber   |
| LED Annunciators Provided                 | Input Overload ( transmitter ), Optical Signal - ON ( receiver )                   |
| Fiber Optic Connectors                    | ST standard, FC available upon request   |
| Power Supplies                            | Wall Mount, Universal, US, UK,<br>Continental Europe and Australian plugs included |
| Power Requirements                        | 95 - 260 VAC, 50 - 60 Hz, 16 VA Max.   |
| Operating Temperature Range               | 0 - 40 C   |
| Weight (each)                             | 0.46 Kg  |
| Transmitter Dimensions ( mm )             | 175 L x 105 W x 40 H   |
| Receiver Dimensions ( mm )                | 175 L x 105 W x 40 H   |
| Standard Warranty                         | Two Years, Components and Workmanship,<br>30 day Satisfaction Guarantee            |
| Accesories Supplied                       | 5 pin DIN connector for digital inputs/outputs, xmtr and receiver                  |

### "Signal Transporter" E/O - O/E Converter Pair

#### LTX-5520 Digital

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net



#### **Benefits**

- Transmits 16 independent TTL signals over a single fiber
- Each channel has 0 to 25 Mb/S bandwidth
- Inputs accepts LVTTL and/or CMOS/TTL
- Outputs are LVTTL (0 3.3 V)
- 850 nm version for multimode links up to 500 M
- 1310 nm version for SM links up to 10 KM
- May be paired with elements of the LTX- 5510 system to configure remote high speed 12-bit A/D and D/A converter modules

The LTX-5520 enables the conveyance of sixteen independent channels of digital information over fiber optic links ranging from meters to more than 10 kilometers.

Each of the 16 incoming TTL channels is sampled at 50 mega-samples per second, multiplexed and transmitted serially over an optical fiber at a 1 Gb/s data rate. The receiver acquires this digital data and demultiplexes it to 16 separate output ports. Each of these channels may be toggled at rates ranging from 0 -25 Mb/S.

Two models are available. Selection depends on the fiber type and the length of the fiber optic link that is required. The LTX-5520-850 transmits at 850 nM over multimode fiber optic links of up to 500 meters in length, while the LTX-5520-1310 transmits at 1310 nm over single-mode fiber to cover distances in excess of 10 kilometers.

The LTX-5510 precision analog fiber optic link was the first in our series of "Signal Transporters". It digitizes an analog signal at a 50 Ms/S rate with 12-bit precision and reconstructs it at the LTX-5510 receiver by means of a fast D/A converter. If the user employs the LTX-5520 receiver with the LTX-5510 transmitter, the result is a remote fiber-coupled 12-bit data acquisition system.

Similarly one can employ the LTX-5520 transmitter with the LTX-5510 receiver to generate fast highresolution analog signals at a remote location.

Applications include data acquistion for plasma physics experiments, signal transmission and control of equipment at high voltage potentials, operation through Faraday shields, and precise noise-free signal transmission in hostile EMI environments.

| LTX-5520 Specifications                  |  |  |
|--|--|--|
| Number of independent channels           | 16   |  |
| Digital Inputs                           | TTL, LVTTL, CMOS compatible  |  |
| Digital Outputs                          | LVTTL ( 0 - 3.3 V)   |  |
| Signal Latency (with one meter of fiber) | ~300 nS  |  |
| Sampling Rate                            | 50 Ms/S  |  |
| Digital Switching Rates                  | 0 - 25Mb/S   |  |
| Digital Signal Edge Uncertainty          | +/-10 nS   |  |
| Laser Wavelength                         | LTX-5520-850: 850 nm +/- 20 nm,<br>LTX-5520-1310: 1310 nm +/- 20 nm              |  |
| Optical Transmission Rate                | 1.0 Gb/s   |  |
| Loss Budget                              | 0 - 15 dB  |  |
| Optical Return Loss                      | > 15 dB  |  |
| Laser Safety Classification              | Class I safety per FDA/CDRH and IEC-825-1 regulations                            |  |
| Typical Transmission Distances (850 nm)  | 500 M with 50/125 MM fiber, 300 M with 62.5/125 MM fiber                         |  |
| Typical Transmission Distances (1310 nm) | 10 KM with 9/125 SM fiber  |  |
| Fiber Optic Connectors                   | ST Type standard, FC available on request  |  |
| Signal connectors                        | DB - 25 on input and output  |  |
| LED Indicators Provided                  | Optical Signal - ON (receiver)   |  |
| Power Supplies                           | Wall Mount, Universal, US, UK. Continental Europe, and Australian Plugs Included |  |
| Power Requirements                       | 95-260 VAC, 50-60 Hz, 16 VA Max  |  |
| Operating Temperature Range              | 0 - 40 C   |  |
| Transmitter Dimensions (mm)              | 175 L x 104 5 x 40 H   |  |
| Receiver Dimensions (mm)                 | 175 L x 104 5 x 40 H   |  |
| Weight Each                              | 0.46 Kg  |  |
| Standard Warranty                        | Two years, Components and Workmanship,<br>30 Day Satisfaction Guarantee          |  |

Fiber Optic

## "Signal Transporter" E/O - O/E Converter pair

LTX-5525

#### **Benefits**

- Transmits 16 independent TTL signals over a single fi ber
- Each channel has a capacity of from 0 50 Mb/S
- Inputs accepts LVTTL and/or CMOS/TTL
- Outputs are LVTTL (0 3.3 V)
- 850 nm version for multimode links up to 300 M
- 1310 nm version for SM links up to 10 KM



The LTX-5525 conveys sixteen independent channels of digital information over a fi ber optic link ranging from meters to more than 10 kilometers. Each of the 16 incoming TTL channels is sampled 100 million times per second, multiplexed and transmitted serially over an optical fi ber at two gigabits per second. The receiver acquires this digital data and de-multiplexes it to 16 separate output ports. Each of these channels supports a channel capacity of 0 to 50 Mb/S.

Two models are available. Selection depends on the fi ber type and the length of the fi ber optic link that is required. The LTX-5525-850 transmits at 850 nM over multimode fi ber optic links of up to 300 meters in length, while the LTX-5525-1310 transmits at 1310 nm over single-mode fi ber to span distances exceeding 10 kilometers.

The new LTX-5525 doubles the data capacity of our previous word-width digital fi ber optic links. Paired with elements of our high-speed analog links,

the LTX-5525 allows the user to confi gure remote precision A/D or D/A converters. This eliminates the need for the user to digitize analog signals at the receiving end of the analog data link.

Applications include data acquisition for plasma physics experiments, signal transmission and control of equipment at high voltage potentials, operation through Faraday shields, and precise noise-free signal transmission in hostile EMI environments.

| LTX-5525 Specifications                  |   |  |
|--|---|--|
| Number of independent channels.          | Sixteen   |  |
| Digital Inputs                           | TTL, LVTTL, CMOS compatible   |  |
| Signal Latency (with one meter of fiber) | ≈ 300 ns  |  |
| Digital Outputs                          | LVTTL, ( 0 - 3.3 V)   |  |
| Input Sampling Rate                      | 100 million samples per second  |  |
| Digital Input Data Rate                  | 0 - 50 Mb/S   |  |
| Digital Signal Edge Uncertainty          | ± 5 ns  |  |
| Laser Wavelength                         | LTX-5525-850: 850 nm ± 20 nm, LTX-5525-1310<br>1310 nm ± 20 nm                  |  |
| Optical Transmission Rate                | 2.0 Gigabit per second  |  |
| Loss Budget                              | 0 - 15 dB   |  |
| Laser Safety Classification.             | Class I safety per FDA/CDRH and IEC-825-1 regulations                           |  |
| Typical Transmission Distances (850 nm)  | 300 m with 50/125 fiber, 175 m with 62.5/125 fiber                              |  |
| Typical Transmission Distances (1310 nm) | 10 Km with 9/125 SM fiber   |  |
| Fiber Optic Connectors                   | ST Type standard, FC available on request                                       |  |
| Signal connectors                        | DB25 on input and output  |  |
| LED Indicators Provided                  | Optical Signal - ON (receiver)  |  |
| Power Supplies                           | Wall Mount, Universal, US, UK. Continental Europe and Australian Plugs Included |  |
| Power Requirements                       | 95-260 VAC, 50-60 Hz, 16 VA Max   |  |
| Operating Temperature Range              | 0 - 40 C  |  |
| Transmitter Dimensions (mm)              | 175 L x 104 5 x 40 H  |  |
| Receiver Dimensions (mm)                 | 175 L x 104 5 x 40 H  |  |
| Weight Each                              | 0.46 Kg   |  |
| Standard Warranty                        | Two years, Components and Workmanship, 30 Day Satisfaction Guarantee            |  |

### **Optical to Electrical** Converter

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

**TIA-525** 



#### **Features**

- · Silicon or InGaAs detectors
- DC to 125 MHz Analog Bandwidth
- Selectable Gain Settings
- Operates from Battery or Line Power
- · Capability to drive 50 Ohm output loads
- Low Noise 3.0 pW/root-Hz

#### **Applications**

- General laboratory testing of optical components
- Field Service Testing and Troubleshooting
- · Laser alignment and tuning
- Plasma physics measurements

The TIA-525 optical receiver is a convenient, easy to use O/E converter. It is extremely useful in a variety of laboratory and fi eld service situations where a quick check of the operation of a laser source, optical transmitter, or the output of a fi ber optic communications link is required. The unit conveniently mounts directly on the vertical input BNC connector of your oscilloscope, digitizer, or other readout device.

Both Silicon and Indium-Gallium-Arsenide detectors are available to cover respectively the 400 to 1000 nm or the 900 to 1700 nm spectral regions. Gains are selectable and provide peak responsivity values of approximately 1000 to 100,000 volts per watt. AC coupling between stages may be introduced in order to examine weak high frequency optical signals in the presence of a strong DC optical component.


The TIA-525 electrical bandwidth exceeds 125 MHz in the low and medium gain configurations and exceeds 35 MHz in the highest gain confi guration.

The unit's output stage is fully capable of driving a 50 ohm coaxial cable terminated in its characteristic impedance. Fiber connector options include either ST or FC receptacles. An unconnectorized detector is optionally available so that the unit may be used with free space beams. Powered by an internal 9V Lithium battery, or its universal power supply, the TIA-525 is handy to use and store.

The ease of use and convienience of this instrument are matched only by the high performance-to-price ratio that is typical of products from Terahertz Technologies. It is also backed by our standard two year warranty and guarantee of satisfaction.

| TIA-525                              | 5 Specifications   |
|--------------------------------------|--|
| Detector Type                        | Silicon or InGaAs (TIA-525S, TIA-525I respectively)                          |
| Analog Signal Bandwidth (-3 dB)      | DC to 125 MHz (Tr = 1.4 K), DC to 35 MHz (Tr = 14 K)                         |
| Selectable Transimpedance settings   | 1.4 K Ohms, 14 K Ohms  |
| Second Stage Gain Selections         | X 1 or X 10  |
| Maximum Linear Input Power           | 1.2 mW   |
| Maximum Input power without damage   | 10 mW  |
| Spectral Response                    | Silicon: 400 to 1000 nm, InGaAs: 850 - 1700 nm                               |
| Output Impediance                    | 50 Ohms  |
| Output Connector                     | Male BNC   |
| Fiber Optic Connector                | Specify FC or ST or Free-Space   |
| Input Numerical Apeture              | 0.29   |
| Inter-stage Coupling                 | DC or AC (100 Hz Low Frequency Cutoff)                                       |
| Output Offset Voltage                | +/- 0.1 Volt   |
| Noise Level                          | 3.0 pW/ root-Hz at peak responsivity   |
| Maximum Output Voltage               | 4 V pk-pk, no load, 2 V pk-pk with 50 Ohm Load                               |
| Power Requirements                   | Power Requirements 9 V Battery or supplied universal wall-mount power supply |
| Battery Life                         | Approximately 30 hours, (no load)  |
| Wall-mount Supply Power Requirements | 95-260VAC, 50 - 60 Hz, 16 VA Max.  |
| Mains Connectors Supplied            | North America, British, Continental Europe, Australian                       |
| Dimensions ( mm )                    | 63 L x 30.5 W x 30 H   |
| Weight                               | 5.6 oz (0.16 Kg)   |
| LED Annunciators Provided            | Power On   |
| Operating Temperature Range          | 0 - 40 C   |
| Standard Warranty                    | Two Years, Componenet and Workmanship, 30 Satisfaction Guarantee             |
| Accessories Supplied                 | Transit Case, Universal Power Supply, 9 V ULTRALIFE Lithium Battery, Manual  |
|                                      |  |

#### To Order



### TSC

# Balanced O/E Converter

**TIA-527** 



#### **Features**

- Matched InGaAs detectors
- DC to 125 MHz Analog Bandwidth
- Selectable Gain Settings
- · Operates from Battery or Line Power
- Capability to drive 50 Ohm output loads
- Low Noise 3.6 pW/root-Hz

#### Applications

- Coherent Heterodyne Detection
- Polaization-Shift-Keying Modulation
- Spectroscopy
- Binary Differential Phase-Shift Keying (2-DPSK)

The TIA-527 balanced optical to electrical converter operates by subtracting the photo currents from two well-matched Indium Gallium Arsenide detectors. The result is then amplifi ed and presented to the output port. Each of the optical signals causes the output to move with a different sense. Common mode signals (e.g. laser RIN noise) are effectively cancelled out.

With selectable gain settings and a bandwidth of DC to 125 MHz this receiver is useful for coherent heterodyne detection applications, differential polarization or phase shifted keying modulation systems, spectroscopy, and similar applications for which the ability to discern small variations in signal strength in two optical paths is critical.

Use of this converter can greatly simplify signal processing requirements downstream from the experiment. Gains of 1400 V/W, 14 000 V/W and 140 000 V/W may be selected as well as selectable AC inter-stage coupling.

The unit is designed to be conveniently mounted on an oscilloscope input BNC connector and may be powered by its internal battery or with the universal wall-mount supply that is provided with each unit.

| TIA-527 Specifications               |  |  |
|--------------------------------------|--|--|
| Detector Type                        | Matched InGaAs   |  |
| Analog Signal Bandwidth (-3 dB)      | DC to 125 MHz (Tr = 1.4 K), DC to 35 MHz (Tr = 14 K)                         |  |
| Selectable Transimpedance settings   | 1.4 K Ohms, 14 K Ohms  |  |
| Gain Selections                      | X 1 or X 10  |  |
| Maximum Linear Input Power           | 1.2 mW   |  |
| Maximum Input power without damage   | 10 mW  |  |
| Spectral Response                    | 850 - 1700 nm  |  |
| Output Impediance                    | 50 Ohms  |  |
| Output Connector                     | Male BNC   |  |
| Fiber Optic Connector                | FC   |  |
| Input Numerical Apeture              | 0.29   |  |
| Inter-stage Coupling                 | DC or AC (100 Hz Low Frequency Cutoff)                                       |  |
| Output Offset Voltage                | +/- 0.1 Volt   |  |
| Noise Level                          | 3.6 pW/ root-Hz  |  |
| Maximum Output Voltage               | 4 V pk-pk, no load, 2 V pk-pk with 50 Ohm Load                               |  |
| Power Requirements                   | Power Requirements 9 V Battery or supplied universal wall-mount power supply |  |
| Battery Life                         | Approximately 30 hours, (no load)  |  |
| Wall-mount Supply Power Requirements | 95-260VAC, 50 - 60 Hz, 16 VA Max.  |  |
| Mains Connectors Supplied            | North America, British, Continental Europe, Australian                       |  |
| Dimensions ( mm )                    | 63 L x 30.5 W x 30 H   |  |
| Weight                               | 5.6 oz (0.16 Kg)   |  |
| LED Annunciators Provided            | Power On   |  |
| Operating Temperature Range          | 0 - 40 C   |  |
| Standard Warranty                    | Two Years, Componenet and Workmanship,<br>30 Satisfaction Guarantee          |  |
| Accessories Supplied                 | Transit Case, Universal Power Supply, 9 V ULTRALIFE Lithium Battery, Manual  |  |

Fiber Optic Product

- 70

### **Optical to Electrical** Converter

**TIA-952** 



#### **Features**

- · Large Area InGaAs detector
- 800 MHz Analog Bandwidth
- Selectable Gain Settings
- Universal Power Supply
- · Capability to drive 50 Ohm output loads
- For use for Single or Multi Mode Fibers

#### **Applications**

- · General laboratory testing of optical components
- · Field Service Testing and Troubleshooting
- Laser alignment and tuning
- · Plasma physics measurements

The TIA-952 optical receiver is a convenient, easy to use O/E converter. It is extremely useful in a variety of laboratory, factory, and field service situations where a quick check of the operation of a laser source, optical transmitter, or the throughput of a fiber optic communications link is required. The unit conveniently mounts directly on the vertical input BNC connector of your oscilloscope, digitizer, or other readout device.

The large area Indium-Gallium-Arsenide detector provided is optimized for use with both single mode and multi mode fibers and covers the 900 to 1700 nm spectral region. Gains are switch selectable and provide peak responsivity values of approximately 500 and 2500 volts per watt. The electrical bandwidth of the TIA-952 exceeds 800 MHz using the low gain setting and exceeds 300 MHz in the high gain mode.

The units output stage is fully capable of driving a 50 ohm coaxial cable terminated in its characteristic impedance. Fiber connector options include either ST or FC receptacles. Powered by a universal wall mount power supply (90 - 260 VAC, 50-60 Hz with four mains adaptors), the TIA-952 is handy to use and store.

The ease of use and convienience of this instrument are matched only by the high performance-to-price ratio that is typical of products from Terahertz Technologies. It is also backed by our standard two year warranty and guarantee of satisfaction.



| TIA-952 Specifications               |   |  |
|--------------------------------------|---|--|
| Detector Type                        | Large area InGaAs   |  |
| Analog Signal Bandwidth (-3 dB)      | 30 KHz to 800 MHz, Low gain, 30 KHz to 300 MHz High Gain                    |  |
| Selectable Responsivity Settings     | 500 V/W or 2500 V/W @ 1550 nm when terminated in a 50 Ohm Load              |  |
| Maximum Linear Input Power           | 2 mW  |  |
| Maximum Input power without damage   | 15 mW   |  |
| Spectral Response                    | InGaAs: 850 - 1700 nm   |  |
| Output Impediance                    | 50 Ohms   |  |
| Output Connector                     | Male BNC  |  |
| Fiber Optic Connector                | Specify FC or ST  |  |
| Input Numerical Apeture              | 0.29  |  |
| Ilnput fiber accomodated             | 9um Single mode or 50/125 & 62.5/125um multi-mode                           |  |
| Output Offset Voltage                | N/A Volts   |  |
| Noise Level                          | 9.5 pW/ root-Hz at peak responsivity  |  |
| Maximum Output Voltage               | Low gain, 2.0 V pk-pk, High Gain 4 V pk-pk, (Into 50 Ohms)                  |  |
| Power Requirements                   | Supplied wall-mount universal power supply                                  |  |
| Wall-mount Supply Power Requirements | 90-260VAC, 50 - 60 Hz, 16 VA Max.   |  |
| Mains Connectors Supplied            | North America, British, Continental Europe, Australian                      |  |
| Dimensions ( mm )                    | 63 L x 30.5 W x 30 H  |  |
| Weight                               | (0.16 Kg)   |  |
| LED Annunciators                     | Provided Power On   |  |
| Operating Temperature Range          | 0 - 40 C  |  |
| Standard Warranty                    | Two Years, Componenet and Workmanship,<br>30 Satisfaction Guarantee         |  |
| Accessories Supplied                 | Transit Case, Universal Power Supply, 9 V ULTRALIFE Lithium Battery, Manual |  |



### **Optical to Electrical** Converter

**TIA-1200** 



#### **Features**

- · Large Area InGaAs detector
- DC to 14GHz Bandwidth
- 900-1700nm
- Universal Power Supply
- · Capability to drive 50 Ohm output loads

#### **Applications**


- · General laboratory testing of optical components
- · Field Service Testing and Troubleshooting
- · Laser alignment and tuning
- · Plasma physics measurements


The TIA-1200 Optical to Electrical Converter is a wide-band detection system for fi ber optic applications. With a typical bandwidth of DC to 14 GHz (min 12 GHz), it accurately provides an electrical replica of the optical signal presented to it. It is intended to drive a 50 ohm cable terminated in its characteristic impedance.

The unit is equipped with an InGaAs/InP detector that is responsive in the wavelength range of 900 - 1700 nm. The TIA- 1200 is provided with an FC or FC/APC fi ber optic receptacle. The output signal is presented to a type K SMA female connector.

The TIA-1200 detector is 50 microns in diameter. Optionally, it may be ordered with a 50 micron fi ber, thus allowing both singlemode and multimode sources to be tested without incurring excessive coupling losses.

Typical optical return loss is 35 dB and is caused primarily by the FC/PC connector employed. If higher return loss is needed. The unit may be optionally equipped with singlemode angled PC connectors for ORLs of around 52 dB.





| TIA-1200 Specifications                   |   |  |
|---|---|--|
| Detector Type                             | InGaAs/InP (900-1700nm)   |  |
| <b>Current Responsivity</b>               | 0.8 A/W @ 1550nm Typical  |  |
| Maximum Liniear Inpurt Power              | 3mw   |  |
| <b>Maximum Input Power without Damage</b> | 10mw  |  |
| Bandwith-(3dB)                            | DC to 14GHz Typical, 12 GHz Minimum                                     |  |
| Output Impediance                         | 50 Ohms   |  |
| Output Connector                          | Type K SMA Female   |  |
| Fiber Optic Input Connector               | FC or FC/APC  |  |
| Input Numerical Apeture                   | 0.11  |  |
| Optical Return Loss                       | >35dB, >52dB with APC Connection  |  |
| Power                                     | Universal Power Supply  |  |
| Dimensions                                | 1.2"W x 2.5"L x 1.5"H ( 30.5mm x 63mm x 38mm)                           |  |
| Weight                                    | 5.6 oz (0.16 Kg)  |  |
| <b>LED Annunciators Provided</b>          | Power On  |  |
| Operating Temperature Range               | 0 - 40 C  |  |
| Standard Warranty                         | Two Years, Componenet and Workmanship,<br>30 Day Satisfaction Guarantee |  |
| Accessories Supplied                      | Transit/Storage Case, Operating Manual, Universal Power Supply          |  |

**Fiber Optic Product** 

Semiconductors

### **Optical to Electrical** Converter

**TIA2000** 



#### **Features**


- DC to 20 GHz Bandwidth typical, 18 GHz min
- Spectral Response 1260 1620 nm
- Universal Power Supply
- Two Year Warranty

#### **Applications**

- RF over fi ber links
- System Characterization
- 20 GHz digital and analog links
- · High speed test and measurent

The TIA-2000 Optical to Electrical Converter is a high speed photodetector module designed for direct optical-to-electrical conversion of RF-modulated optical signals and provides a typical bandwidth of DC-20 GHz. The optical input is supplied through a singlemode 9/125 fi ber connector equipped with an ultra-polish FC-PC connector or optionally an angle polished, low refl ection FC/APC connector. The RF output of the device is provided through a high performance SMA connector. The typical optical responsivity is 22 V/W at 1550 nm when the unit is terminated with a 50 ohm load.

#### Typical Setup of the TIA-2000



| TIA-2000 Specifications            |   |  |  |
|------------------------------------|---|--|--|
| Detector Type                      | InGaAs/InP (1260-1620nm)  |  |  |
| Current Responsivity               | 0.8 A/W @ 1550nm Typical  |  |  |
| Maximum Linear Input Power         | 3mw   |  |  |
| Maximum Input Power without Damage | 10mw  |  |  |
| Bandwith-(3dB)                     | DC to 20 GHz Typ, 18 GHz min.                                       |  |  |
| Output Impedance                   | 50 Ohms   |  |  |
| Output Connector                   | Type K SMA Female   |  |  |
| Fiber Optic Input Connector        | FC/UPC or FC/APC  |  |  |
| Input Numerical Aperture           | 0.11  |  |  |
| Optical Return Loss                | >35dB, >52dB with APC Connection                                    |  |  |
| Electrical Return Loss             | 10 dB   |  |  |
| Power                              | Universal Power Supply  |  |  |
| Dimensions                         | 1.2"W x 2.5"L x 1.5"H ( 30.5mm x 63mm x 38mm)                       |  |  |
| Weight                             | 5.6 oz (0.16 Kg)  |  |  |
| LED Annunciators Provided          | Power On  |  |  |
| Operating Temperature Range        | 0 - 40 C  |  |  |
| Standard Warranty                  | Two Years, Component and Workmanship, 30 Day Satisfaction Guarantee |  |  |
| Accessories Supplied               | Transit/Storage Case, Operating Manual, Universal Power Supply      |  |  |



### **Optical to Electrical** Converter

**TIA-3000** 



#### **Features**

- Wavelength Response 900nm to 1700nm
- · Low Noise, High Gain
- Responsivity 450V/W
- Bandwidth- 11 GHz (SM)
- Type K SMA Output Electrical Connector
- FC/UPC Style Fiber Optic Input Connector

#### **Applications**

- · General Laboratory Testing of Optical Components
- Front-End O/E Converter For Test Instruments
- · Rapid Doppler-Shift LIDAR Measurments
- · Analog RF Links Over Fiber

The TIA-3000 is a versatile Optical to Electrical converter for laboratory or field use. This low profile O/E converter will faithfully reproduce an optical signal on a wide range of oscilloscopes and digitizers.


The unit is equipped with an InGaAs/InP detector that is responsive in the wavelength range of 900 - 1700 nm. The TIA-3000 bandwidth ranges from 30KHz to 10GHz (-3dB).


Applications for this converter include the General purpose testing of fiber optic components, data links and transmitter testing, LIDAR and analog RF-over-fiber links.

The TIA-3000 like other Terahertz Technologies Inc. TIA O/E devices are shipped in a hard case with universal power supply that has interchangeable AC plugs.

| Detector Type                             | InGaAs/InP (900nm-1700nm)  |
|---|--|
| Current Responsivity                      | 0.8 A/W @ 1550nm Typical   |
| Maximum Liniear Input Power               | 2mw  |
| Maximum Input Power without Damage        | 3mw  |
| Bandwith@1550nm Typ.                      | 11 GHz   |
| Output Impediance                         | 50 Ohms  |
| Output Connector                          | Type K SMA Female  |
| Fiber Optic Input Connector               | FC/UPC   |
| Input Numerical Apeture                   | 0.11   |
| Noise Figure                              | 3dB  |
| Detector Optical Return Loss @1550nm Typ. | 30dB   |
| Power                                     | Universal Power Supply   |
| Dimensions                                | 1.2"W x 2.5"L x 1.5"H ( 30.5mm x 63mm x 38mm)                        |
| Weight                                    | 5.6 oz (0.16 Kg)   |
| LED Annunciators Provided                 | Power On   |
| Operating Temperature Range               | 0 - 40 C   |
| Standard Warranty                         | Two Years, Componenet and Workmanship, 30 Day Satisfaction Guarantee |
| Accessories Supplied                      | Transit/Storage Case, Operating Manual, Universal Power Supply       |
|   |  |

**TIA-3000 Specifications** 





### Photodiode Transimpedance Amplifier

PDA-750



- Eight Decade Dynamic Range
- · Less Than 1 pA Noise
- Maximum Resolution 1 part in +/- 20 000
- Rechargeable Ni-mH Batteries for Low Noise
- Digital Input of A/W value yields readout in Watts
- Computer Interface for easy control
- Background Cancelation of +/- 200 %
- Digitally set bias source from -14.00 tp +14.00 V

The PDA-750 is a low noise, high gain, transimpedance amplifi er designed to provide a direct digital readout of the current generated from a photodiode photomultiplier, or other similar current source. With full scale input ranges of  $\pm$  20 nA to  $\pm$  20 mA and a noise level of less than 1 pA, the PDA-750 offers superb dynamic range.

Digital entry of an Amps/Watt setting via the front panel controls permits the instrument to display current measurements in units of Watts. The A/W setting ranges from 1.000 to 0.100.

A variable bias supply is built into the instrument and may be switched into series with the device under test. It can supply digitally selectable voltages ranging from -14.00 to + 14.00 volts.

The Offset control permits the nulling of background signals as large as ± 200% of the range currently in use.

Rechargeable batteries isolate the unit from the mains and eliminate the effects of ground loops and/ or power line noise that may be present during sensitive measurements. They will power the instrument for approximately 10 hours between charges. The unit may be operated normally while the batteries are charging.

The large 4 1/2 digit Liquid Crystal Display provides a maximum resolution of 1 part in ±20,000, thus enabling the detection of very small changes in the signal under test.

An analog output port provides a  $\pm$  2 Volt full-scale signal that is directly proportional to the display reading of  $\pm$  20,000 counts.

The PDA-750 is equipped with a bi-directional Rs-232 serial port that enables the user to remotely control the instrument and read data and the instrument's status.

Applications for the PDA-750 include: serving as a precision readout device for Unity Quantum Effi cient detectors such as the QED-150 manufactured by UDT Instruments, characterization of detector dark current, a readout interface for spectrometers, spectral calibration of detectors, a high gain precision transimpedance amplifi er and as a sensitive, high precision optical power meter.

The ease of use and convenience of this instrument is typical of TTI products. This instrument is covered by our standard two year limited warranty and guarantee of satisfaction.



| PDA-750 Photodiode Amplifier Specifications   |   |  |  |  |  |
|---|---|--|--|--|--|
| Full Scale Ranges   | ± 20 nA to ± 20 mA in decade steps,<br>1 pA maximum resolution          |  |  |  |  |
| Measurement Uncertainty ± 0.05 % of Reading ± 2 Least Significant Digits                          |   |  |  |  |  |
| Maximum Input Current Without Damage  | ± 25 mA   |  |  |  |  |
| A/W Setting   | 0.100 to 1.000 A/W in increments of .005 A/W                            |  |  |  |  |
| Input Impedance (DC to 2 KHz)   | Zero Ohms Virtual Ground, Single Ended                                  |  |  |  |  |
| Input Capacitance   | 25 pF   |  |  |  |  |
| Output Impedance  | 100 Ohms  |  |  |  |  |
| Bias Voltage  | Selectable from - 14 V to + 14 V in 6.5 mv increments                   |  |  |  |  |
| Analog Output Port  | ± 2 V corresponds to ± 20 000 counts of range in use                    |  |  |  |  |
| Noise and Drift   | < ± 1 pA/5 seconds on most sensitive range                              |  |  |  |  |
| Background Cancelation ± 200 % of the range in use  |   |  |  |  |  |
| Analog Output Port Frequency Response   | DC to 2 KHz, most sensitive range, DC to 40 KHz, least sensitive range  |  |  |  |  |
| Rs-232 Interface  | 9600 Baud, N-8-1, 3 wire, Bi-directional, Cable Provided                |  |  |  |  |
| Display   | 4 1/2 Digit LCD, 0.4 " high   |  |  |  |  |
| Power Requirements  | Rechargeable Ni-mH batteries provide approximately 10 hours of use      |  |  |  |  |
| External Power Supply/Charger   | 85 - 250 VAC, 50-60 Hz, < 9 VA  |  |  |  |  |
| Mains Adaptors Adaptors Adaptors provided for US, Continental Europe, Great Britain and Australia |   |  |  |  |  |
| Operating Temperature Range   | 0 - 40 C  |  |  |  |  |
| <b>Dimensions</b> 5.5" W x 2.5" H x 8.5" L (140 x 63 x 215 mm)                                    |   |  |  |  |  |
| Weight  | 2 Lbs., 0.9 kg (excluding external power supply)                        |  |  |  |  |
| Interconnecting cable supplied  | Rs-232, 14 feet max length  |  |  |  |  |
| CE Certification  | Yes   |  |  |  |  |
| Accessories Provided  | Rs-232 cable, Power Supply/Charger, Operating Manual                    |  |  |  |  |
| Standard Warranty   | Two years, Components and Workmanship,<br>30 Day Satisfaction Guarantee |  |  |  |  |
| Application Software Provided   | Downloadable from TTI website, www.terahertztechnologies.com            |  |  |  |  |

PDA-750 Photodiode Amplifier Specifications



Fiber Optic

## 1500 Series **Power Meters And Light Sources**

#### **Features**

- · Automated loss measurements for three wavelengths
- · Auto wavelength switching
- · Universal Power Meter and Light Source adapters FC/ST and SC
- Power Meter with -75 dBm Dynamic Range
- · Single port Laser source with up to three wavelengths
- · Storage for 2000 triple wavelength loss measurements
- Rechargeable Li polymer 9V battery
- · USB interface
- · Free Windows® compatible report software
- Reference level storage



The 1500 series are small, rugged automated fiber optic Power Meters and single port Light Sources available in single, dual or triple wavelengths. The power meter uses a sensitive InGaAs detector, calibrated at six wavelengths with a 75 dB dynamic range.

When PM-1500 power meter and LS-1500-X light sources are used together, they can operate in autotest mode where the Light Source changes wavelengths at a fixed rate and informs the Power Meter of the wavelength currently being measured. Up to 2000 triple wavelength measurements may be stored and recalled via the unit's USB port or from the front panel. Windows® compatible PC application software is provided for downloading stored data and printing professional reports.

The Light Source has a selectable single port output for constant wave or modulated wave signal. The Power Meter performs fiber identification functions with the modulation mode of the LS-1500-X or any other light source with modulation frequencies of 270, 1000 or 2000 Hz. Power is obtained from a rechargeable lithium polymer battery. Both units are supplied with a universal power supply, and in a pinch, any common 9V alkaline battery may be used.

Accessories included with both power meters and light sources are heavy duty case, protective rubber boot with stand, adaptors for FC, ST or SC connectors, universal power supply/ charger, and manual. The power meter is also supplied with a CD containing application software and operating instructions plus a USB cable. All power meters and light sources carry a two year, components and workmanship warranty and a 30 Day Satisfaction Guarantee.

#### Ordering Information

| Singlemode Light Sources |  |  |
|--------------------------|--|--|
| LS-1500-3                | 1310nm Singlemode Light Source           |  |
| LS-1500-4                | 1490nm Singlemode Light Source           |  |
| LS-1500-5                | 1550nm Singlemode Light Source           |  |
| LS-1500-35               | 1310/1550nm Singlemode Light Source      |  |
| LS-1500-345              | 1310/1490/1550nm Singlemode Light Source |  |

| Power Meters |                  |  |
|--------------|------------------|--|
| PM-1500      | Power Meter      |  |
| PM-1500C     | CATV Power Meter |  |

| Multi-Mode Light Source |             |                                    |
|-------------------------|-------------|------------------------------------|
|                         | LS-1500-813 | 850/1300nm Multi-Mode Light Source |

| 1500 Series Specifica tions   |  |  |  |  |
|---|--|--|--|--|
| Power Meter Specifi cations   |  |  |  |  |
| Power Meter Detector Type   | InGaAs   |  |  |  |
| Calibrated Wavelengths  | 850, 1300, 1310, 1490, 1550, 1625 nm   |  |  |  |
| Units of Measurement  | dBm, dB,   |  |  |  |
| Resolution  | 0.01dB   |  |  |  |
| Power Input Range   | +5 dBm to - 77 dBm (CATV +25 dBm to -57dBm)  |  |  |  |
| Power Measurement Uncertainty   | ± 0.18 dB under reference conditions, ± 0.25 dB from 0 to -65 dBm,<br>± 0.35 dB from 0 to +5 dBm and from -65 to -77 dBm |  |  |  |
| Autotest Measurement Rate   | Four seconds per wavelength  |  |  |  |
| Autotest Range  | 0 to - 36 dB   |  |  |  |
| Storage Locations   | 2000   |  |  |  |
| Battery/Operating Time  | Rechargeable Li Polymer/Approximately twenty hours following a full charge   |  |  |  |
| Power Supply / Charger  | Universal, US, UK, Continental Europe, and Australian Plugs Included   |  |  |  |
| Power Requirements  | 95-260 VAC, 50-60 Hz, 3 VA Max   |  |  |  |
| Operating Temperature Range   | -10 to 45 C  |  |  |  |
| Storage Temerature Range  | Equipment -10 to 60C, Battery 0-40C  |  |  |  |
| Dimensions (with rubber boot )  | 5.9" L x 3.9" W x 1.37" H (150mm L x 100mm W x 35mm H)   |  |  |  |
| Weight  | 0.52 Kg  |  |  |  |
| Accessories Provided FC, ST, SC adaptors, rubber boot, battery, power supply/chamanual, USB Cable, PC application. Software |  |  |  |  |
| Light Source Specifi cations  |  |  |  |  |
| Laser Output Power  | 0 dBm, 1 mw  |  |  |  |
| Output Stability ± .05 dB / 24 hrs @ constant temp,, ± .02 dB/C temperature coeffi  |  |  |  |  |
| Laser Wavelengths Provided 850nm, 1300nm, 1310 nm ± 20 nm, 1490 ± 20 nm, 1550 ± 20 nm                                       |  |  |  |  |
| Spectral Width  | < 3nm typ.   |  |  |  |
| Modulation Modes  | CW, 270 Hz, 1000 Hz, 2000 Hz   |  |  |  |
| Autotest Measurement Rate   | Four seconds per wavelength  |  |  |  |
| Laser Safety Classifi cation.   | Class I safety per FDA/CDRH and IEC-825-1 regulation   |  |  |  |
| Battery   | Rechargeable Li Polymer  |  |  |  |
| Operating Time  | Approximately fi fteen hours following a full charge   |  |  |  |
| Power Supply / Charger  | Universal, US, UK. Continental Europe, and Australian Plugs Included   |  |  |  |
| Power Requirements  | 95-260 VAC, 50-60 Hz, 3 VA Max   |  |  |  |
| Operating Temperature Range   | -0 to 40 C   |  |  |  |
| Storage Temerature Range  | Equipment -10 to 60C, Battery 0-40C  |  |  |  |
| Dimensions (with rubber boot )  | 5.9" L x 3.9" W x 1.37" H (150mm L x 100mm W x 35mm H)   |  |  |  |
| Weight  | 0.52 Kg  |  |  |  |
| Accessories Provided  | FC, ST, SC adaptors, rubber boot, battery, power supply/Charger, manual  |  |  |  |


### **Optical Oscilloscope Probe**


**TIA-4000** O/E Converter



#### **Benefits**

- Wavelength Response 950 nm to 1650 nm
- Low Noise, High Gain
- · Gain Settings from 2 to 7
- Bandwidth 30 KHz to 7 GHz typical
- SMA type K Output Electrical Connector
- FC/APC Style Fiber Optic Input Connector






The TIA-4000 is comprised of a fi ber coupled InGaAs APD detector combined with a variable reverse bias voltage network and fast transimpedance amplifi er. The output of the unit brought out to a type K female SMA connector. Light falling on the detector generates a positive-going proportional current. This current, multiplied by the transimpedance produces a voltage that is proportional to the light incident on the detector


Normally the unit is used to drive a coaxial cable, this cable should have a 50 ohm characteristic impedance and be terminated with a 50 ohm load at the oscilloscope or other measuring device to be used.

The active area of the TIA-4000 is 30 microns in diameter. It is coupled to a single mode optical fi ber. Typical optical return loss is 52 dB and is caused primarily by the FC/APC connector employed.

The applied bias voltage controls the gain of the APD. This voltage in turn, is controlled by means of the two push buttons on the top panel. The rightmost button increases the gain and the leftmost button decreases the gain. There are 64 discrete gain settings that are retained in non-volatile memory when the power is turned off. Thus the gain setting will be retained even though power is disconnected from the unit.

Pressing a button once causes the unit to advance in the selected direction by one step. Holding the button down causes the unit to advance automatically until a limit is reached.





#### **Operating Considerations**

The TIA-4000 is comprised of a fi ber coupled InGaAs APD detector coupled with a variable reverse bias voltage network and fast transimpedance amplifier. The output of the unit brought out to a type K female SMA connector. Light falling on the detector generates a positive-going proportional current. This current, multiplied by the transimpedance produces a voltage that is proportional to the light incident on the detector surface.

Normally the unit is used to drive a coaxial cable, this cable should have a 50 ohm characteristic impedance and be terminated with a 50 ohm load at the oscilloscope or other measuring device to be used. The active area of the TIA-4000 is 30 microns in diameter. It is coupled to a single mode optical fi ber. Typical optical return loss is 52 dB and is caused primarily by the FC/APC connector employed.

The applied bias voltage controls the gain of the APD. This voltage in turn, is controlled by means of the two push buttons on the top panel. The rightmost button increases the gain and the leftmost button decreases the gain. There are 64 discrete gain settings that are retained in nonvolatile memory when the power is turned off. Thus the gain setting will be retained even though power is disconnected from the unit.

Pressing a button once causes the unit to advance in the selected direction by one step. Holding the button down causes the unit to advance automatically until a limit is reached.

Fiber

Optic

### **Optical Time Domain** Reflectometer

#### FTE7500

#### **Features**

- Instant On
- · Fast Real time
- 32 dB Dynamic Range
- · Event Table with Pass/Fail Feature
- Short Dead Zone
- · SM, MM and Quad Units Available
- · One Button Testing
- Trace Overlay Capability
- Onboard Memory for 1000 traces
- · Integrated Auto-Wavelength Loss Test Set
- · Visible Fault Locator
- · USB Flash Drive Port and Mini USB Port
- On-Screen Tutorials
- Light Weight Rugged Enclosure
- Easy To Read Color Display
- Telcordia SR4731 Compatible Software Included
- Long Battery Life




The TTI Future Gen OTDR is fast, easy to use, affordable and rugged. This OTDR boasts all the features that are truly needed in a hand-held OTDR. It has a short dead zone, bright 4" color display and with an onboard context sensitive help system the OTDR has a minimal learning curve for all users. The 1/2 second trace updates and great dynamic range make this unit perfect for maintenance and trouble shooting. All these aspects of the Future Gen OTDR are what makes it ideal for every day use in the fi eld on a wide variety of networks. This OTDR can be operated by the novice while at the same time be appreciated by the seasoned user.

The FTE-7500 is sold in a variety of confi gurations and is standard in dual single mode, dual multimode and quad wavelength confi gurations. Use the Autotest button for one button testing. Examining the trace is easy using the straight forward zoom feature, A/B cursor selection button and touch-wheel. Move to events easily by pressing the select button while in trace view or with an event highlighted in the Event Analysis screen. The Future Gen OTDR's abundant dynamic Range and a 2 meter dead zone, makes it ideal for links up to 240km as well as being perfect for short LAN links within the facility. The TTI FTE-7500 weighs in at less then 2.0 pounds with a hardened water resistant enclosure, this OTDR is great for all conditions. The rubber boot with bail will add protection and provides the ideal angle for viewing the display while operating on a work bench. Trace analysis and reporting is fast and easy with a Pass/Fail feature, onboard event table and the supplied Telcordia SR4731 compatible software with multi-trace capability. The OTDR has on board storage of 1000 traces with the ability to download traces directly to your computer via USB cable or use a USB Flash Drive. Use the integrated power meter and light source capabilities to accomplish insertion loss test measurements. When paired with our companion power meter or light source the units have autowavelength and auto-test capabilities for advanced end to end measurements.

|       | Free H          | 1147  | Orfochi Bill   | 1000    |
|-------|-----------------|-------|----------------|---------|
| de l  | Series In 1981  | 114   | Owthought Bild |         |
| 89    | Orten 11, 890   | 195   | Definite Rift  | 3 111   |
| (MCS) | Defs.11.865     | 216   | Sefault itse   | 2000    |
| R(n)  | Oct 44.11, 664  | 162   | Ortio 11 617   | 99.08   |
| 975   | Series 14, 995  | 1940  | Series 34.818  |         |
| **    | Orto, 11,000    | - 911 | CITED AND      | 1.44    |
| 80    | 2e1ec11.667     | 1990  | 2e fee 11: 808 | 10000   |
| ès    | Setje, 11. mm   | 96/1  | Default 921    | - Durry |
| 80    | Derfey 11,007   | 100   | Online31: 903  | - 20    |
| 200   | Sefect # 818    | -     | Water 473      | Day     |
|       | Octob 13. 513   | -     |                |         |
| 914   | Serfex 11 (618) |       | 25.0           |         |

Trace Analysis Screen



Printout from Report Software

|     |     |     | - | == |
|-----|-----|-----|---|----|
|     |     | 74, |   |    |
|     |     | -   | 4 | 3  |
| THE | Th. | ī   | ñ | Ē  |

| FTE7500-OTDR Specifi cations    |   |
|---------------------------------|---|
| Wavelength                      | 850, 1300, 1310, 1550, 1625nm ±20nm                     |
| Dynamic Range                   | 27/26dB MM, 32/30dB SM, 30/29/29 TRI                    |
| Pulse Width                     | 20 - 10,000 ns  |
| Units of Measurement            | km, kf  |
| Event Dead zone                 | 2m  |
| Attenuation Dead Zone           | 5m  |
| Resolution                      | .25 - 64m   |
| Distance Uncertainty            | ±(0.75m + 0.005% x distance + sampling resolution)      |
| Full Scale Distance Range       | 1-64km MM , 1-240km SM                                  |
| Typical Real-time Refresh Rate  | 4 Hz  |
| Group Index of Refraction (GIR) | 1.024 - 2.048   |
| inearity                        | ± .05 dB/dB   |
| Memory Capacity                 | 1000  |
| Memory Type                     | Internal and Flash Drive                                |
| Power Supply / Charger          | Universal   |
| Battery                         | 8hr   |
| Storage Temperature             | -20 to 60 C   |
| Operating Temperature Range     | -10 to 50 C   |
| Dimensions (w/out rubber boot ) | 7.75" L x 4.5" W x 2.25" H (197mm L x 114mm W x 57mm H) |
| Weight                          | 2 lbs   |
| Communications ports            | USB and USB Flash Drive Ports                           |
| Connector Styles                | FC, ST, SC Interchangeable                              |

TTI reserves the right to change specifi cations without notice.

Accessories Provided

| Visible Light Source |  |  |
|----------------------|--|--|
| Emitter Type         | Laser  |  |
| Wavelength           | 650nm ±5nm   |  |
| Laser Safety         | Class Class IIFDA21 CFR1040.10<br>&1040.11 IEC 825-1: 1993 |  |
| Connector Type       | 2.5mm Universal  |  |
| Output Power         | 1mW Max.   |  |

| Light Source Specifi cations |  |  |  |
|------------------------------|--|--|--|
| Fiber Type Single mode       |  |  |  |
| Wavelengths                  | 850, 1300, 1310, 1550, 1625 nm<br>±20nm                                    |  |  |
| Output Power                 | 0 dBm<br>(-3dBm @ 1625nm)  |  |  |
| Laser Safety                 | Classifi cation Class I Safety<br>Per FDA/CDRH and IEC-825-1<br>Regulation |  |  |
| Modulation Modes             | CW, 270 Hz, 1000 Hz, 2000 Hz   |  |  |

Universal Power Adapter w/US, UK, Continental Europe, and Australian Plugs,

Interchangeable FC/ST and SC Adapters, Windows/Telcordia SR4731 Software,

| <b>Power Meter Specifi cations</b> |   |
|------------------------------------|---|
| Detector Type                      | InGaAs  |
| Connector Type                     | 2.5mm Interchangeable   |
| Dynamic Range                      | +5 to -77dB   |
| Calibrated Wavelengths             | 850,1300,1310,1490,1550,1625nm  |
| Units of Measurement               | dBm, dB   |
| Resolution                         | .01 dB  |
| Power Measurement Uncertainty      | $\pm$ 0.18 dB under reference conditions, $\pm$ 0.25 dB from 0 to -65 dBm, $\pm$ 0.35 dB from 0 to +5 dBm and from -65 to -77 dBm |
| Power input Range                  | +5 to -77dBm  |
| Autotest Range 0 to                | -40dB   |

Optic

### **Viper Optical Time Domain Reflectometer**

#### FTE7000

#### **Features**

- · Most Affordable OTDR on the Market
- Short Dead Zone
- 32 dB Dynamic Range
- · Integrated Loss Test Set
- · Ultra Fast Trace Acquisition
- · One Button Testing
- Short Dead Zone
- Trouble Shooting with VFL
- Event Table with Pass/Fail Feature
- Trace Comparison with Trace Overlay
- Super Simple Graphical User Interface
- · Easy Training with Onboard Help Screens
- · Telcordia Compatible Software Included
- · Light Weight Rugged Enclosure
- SM and MM Units Available
- Onboard Memory for 1000 traces
- Easy To Read Color Display



The FTE-7000 Viper OTDR is the most affordable Hand- Held OTDR on the Market today with all of the features of more expensive units. Features such as Trace Overlay, Visual Fault Locator, Loss Test Set, Color Display, One Button Autotest and Event Analysis are included. These are features one would expect to find on units costing thousands more. This OTDR can be operated by the novice while at the same time appreciated by the seasoned user.

This unit is available in dual single mode, dual multimode and single wavelength versions Testing is made simple and fast with the press of the Auto Test button. Examine the trace using the straight forward zoom feature and A/B cursor selection button. Zero in on events fast with the powerful event selection feature or with the event analysis table.

The FTE-7000 OTDR's abundant dynamic range and a 2 meter dead zone, makes it ideal for links up to 240km as well as being perfect for short LAN links within the facility. Weighing in at just over one and a half pounds, this OTDR is ideal for all conditions. The rubber boot with bail adds protection and provides the ideal angle for viewing the display while operating on a work bench.

Use the integrated power meter and light source capabilities to accomplish insertion loss test measurements. When paired with our companion power meter or light source the units have auto-wavelength and auto-test capabilities for advanced end to end measurements.

Trace analysis and reporting is fast and easy with the Pass/ Fail feature, onboard event table or the supplied Telcordia SR4731 compatible software with multitrace capability. The OTDR has on board storage of 1000 traces and 10,000 lost tests with the ability to download traces directly to your computer via USB cable.

| NAME AND            |           |               |  |  |                                      |
|---------------------|-----------|---------------|--|--|--------------------------------------|
| The STATES          |           | -             | Special De   |  |                                      |
| of the later of the | -         | _             | THE PERSON NAMED IN  | 100  |                                      |
| A STATE OF          | _         | $\rightarrow$ | and the same   | Alleria  |                                      |
| 18.83               |           | -             | - A 10   |  |                                      |
|                     |           |               |  |  |                                      |
| 202                 | 161       | 742           | 9,750  | 107  | Sec.                                 |
| 4                   | - 14      | -             |  | -  | 11111                                |
|                     | -         |               |  | 1  | _                                    |
|                     |           |               |  | -  | _                                    |
| 200                 |           |               |  |  |                                      |
|                     |           |               |  |  |                                      |
|                     |           |               |  |  |                                      |
|                     | 1         | -             | -  |  |                                      |
|                     | 1         | -             |  |  | -                                    |
|                     | 1         |               | - 1  | -  | -                                    |
|                     |           | -             | - 1  |  |                                      |
|                     | -         |               | - 1  | -  | -                                    |
|                     | -         |               | - 1  | •  |                                      |
|                     | -         |               | - 1  |  |                                      |
|                     | -         |               | - 1  | -  | Too far                              |
|                     | -         |               | - 1  | 200 E  | Time Tipe<br>Tipe<br>Tipe<br>Tipe    |
|                     | -         |               | - 1  | COLUMN CO | Time Tige<br>Time Tige<br>Time Tiges |
| . 6                 | Section 1 |               | If we light with the light will be a light will be a light will be a light with the light will be a | 200 E  | Time Time<br>Time Time<br>Time Time  |

The FTE-7000 is shipped with Telcordia compatible software for easy report

| Wavelength                        | 850, 1300, 1310,1550, ±20nm   |
|-----------------------------------|---|
| Dynamic Range                     | 27/26dB MM, 32/30dB SM<br>(FTE-7000E-1310-30dB)   |
| Pulse Width                       | 20 - 10,000 ms  |
| Units of Measurement              | km, kf  |
| Event Dead zone                   | 2m  |
| Attenuation Dead Zone             | 5m  |
| Resolution                        | .25 - 64m   |
| Distance Uncertainty              | ±(0.75m + 0.005% x distance + sampling resolution)  |
| Full Scale Distance Range         | 1-54km MM , 1-240km SM  |
| Typical Real-time Refresh Rate    | 4 Hz  |
| Group Index of Refraction (GIR)   | 1.024 - 2.048   |
| Linearity                         | ± .05 dB/dB   |
| Memory Capacity                   | 1000  |
| Memory Type                       | Internal  |
| Power Supply / Charger            | Universal   |
| Battery                           | Ahr   |
| Storage Temperature               | -20 to 60 C   |
| Operating Temperature Range       | -10 to 50 C   |
| Dimensions (without rubber boot ) | 7.62" L x 3.88" W x 1,58" H<br>(194mm L x 99mm W x 40mm H   |
| Weight                            | 1.6 lbs.  |
| Communications ports              | USB   |
| Connector Styles                  | FC, ST, SC Interchangeable  |
| Accessories Provided              | Universal Power Adapter w/<br>US, UK, CE, and AU Plugs,<br>Interchangeable FC/ST and SC<br>Adapters, Windows/Telcordia<br>SR4731 Software, Rubber Boot<br>USB Cable, Manual |

| 171 reserves | 46.0 | made to chick | the stand   | brokens . | without when    |   |
|--------------|------|---------------|-------------|-----------|-----------------|---|
| 311110001993 | -    | Mind In FLINE | the streets | manum.    | BUCKLE OF STATE | J |


| FTE-7000-850   | Multimode OTDR 850nm WLTS            |
|----------------|--------------------------------------|
| FTE-7000-1300  | Multimode OTDR 1300nm WILTS          |
| FTE-7000-8513  | Dual Multimode OTDR 850/1300nm W/LTS |
| FTE-7000-1310  | Single mode OTDR 1310nm WILTS        |
| FTE-7000-1550  | Single mode OTDR 1550nm WLTS         |
| FTE-7000-1315  | Single mode OTDR 1310/1550nm W/LTS   |
| FTE-7000E-1310 | Economy SM 1310 OTDR (No VFL or LTS) |
| FTE-7000-BC    | Auxiliary Charger Kit                |

| Visible Light Source |   |
|----------------------|---|
| Emitter Type         | Laser   |
| Wavelength           | 650nm ±5nm  |
| Laser Safety Class   | Class IFDA21 CFR1040.10<br>&1040.11 IEC 825-1, 1993 |
| Connector Type       | 2.5mm Universal                                     |
| Output Power         | 1mW Max.  |

| Detector Type                    | InGaAs   |
|----------------------------------|--|
| Connector Type                   | 2.5mm Interchangeable  |
| Dynamic Range                    | +5 to -77dB  |
| Calibrated Wavelengths           | 850,1300,1310,1490,1550,1625nm   |
| Units of Measurement             | dBm, dB  |
| Resolution                       | .01 dB   |
| Power Measurement<br>Uncertainty | e C. 10 diffusioni refluence conditions, e S. 20 different<br>Chia -40 differ.<br>e E 25 diffusioni ha ni allina and have 40 fai 77 differ |
| Power input Range                | +5 to -77dBm   |
| Autotest Range                   | 0 to -40dB   |

| Fiber Type                  | Single mode   |
|-----------------------------|---|
| Wavelengths                 | 850, 1300, 1310, 1550, 1625 nm<br>±20nm                 |
| Output Power                | 0 dBm (-3dBm @ 1625nm)                                  |
| Laser Safety Classification | Class I Safety Per FDA/CDRH and<br>IEC-825-1 Regulation |
| Modulation Modes            | CW, 270 Hz, 1000 Hz, 2000 Hz                            |

Til reserves the right to change specifications without notice.







**1500 Series Fiber Optic** 

**Loss Test Equipment** 

#### **Features**

- · Automated loss measurements
- · Auto wavelength switching

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

- · Up to three Wavelengths in one source
- Interchangeable Power Meter adapters
- Interchangeable Light Source adapters
- · Power Meter with 80+ dB Dynamic Range
- Single port laser source
- Storage for 2000 multi wave test
- Rechargeable Li polymer 9V battery
- USB interface
- Free Windows® compatible report software



1500 Series Loss Test Equipment The 1500 is available as a Loss Test Set or as a stand alone Power Meter or Light Source.

InGaAs Power Meter InGaAs based optical power meter calibrated at six wavelengths and has an +5 to -77 dBm measurement range.

Auto Test In the Autotest mode, the master unit changes wavelengths at a fi xed rate and informs the slave unit of the wavelength currently being measured.

Auto Wavelength Recognition The Power Meter recognizes the wavelength being tested to help eliminate costly errors.

Available Wavelengths The stabilized laser light source has up to three selectable wavelengths and the power meter is calibrated at 850, 1300, 1310, 1490, 1550 and 1625nm.

Small Size and Rugged The 1500 Series is built into a very small package that is rugged and lightweight.

Fiber Identifi cation The units also performs fi ber identifi cation functions with modulation frequencies of 270, 1000 and 2000 Hz.

Power Options Power is obtained from a rechargeable lithium polymer battery or in a pinch, any common 9V alkaline battery.

Test Storage Store up to 2000 three wavelength tests and download the information to your PC via USB with the supplied Windows™ compatible software

Purchase as a Loss Test Set or as Power Meters and Light Sources Kits



#### **Specifications**

| Power Meter                   |   |
|-------------------------------|---|
| Power Meter Detector Type     | InGaAs  |
| Measurement Range             | +5 dBm to - 77 dBm (CATV +25 dBm to -57dBm)   |
| Calibrated Wavelengths        | 850, 1300, 1310, 1490, 1550, 1625 nm  |
| Units of Measurement          | dBm, dB,  |
| Resolution                    | 0.01dB  |
| Power Measurement Uncertainty | ± 0.18 dB under reference conditions, ± 0.25 dB from 0 to -65 dBm,<br>± 0.35 dB from 0 to +5 dBm and from -65 to -77 dBm        |
| Auto Test Range               | 0 to -36 dB   |
| Storage Locations             | 2000  |
| Light Source                  |   |
| Laser Output Power            | 0 dBm, 1mw  |
| Output Stability              | ± .05 dB / 24 hrs. @ constant temp,, ± .02 dB/C temperature coeffi cient  |
| Laser Wavelengths Provided    | 850nm, 1300nm, 1310 nm , 1490, 1550 (± 20 nm)   |
| Modulation Modes              | CW, 270 Hz, 1000 Hz, 2000 Hz  |
| Laser Safety Classification   | Class I safety per FDA/CDRH and IEC-825-1 regulation  |
| General                       |   |
| Display                       | LCD, power reading, 0.4" high digits, .01 dB resolution Power meter, laser wavelength display 0.16" high digits                 |
| Battery/Operating Time        | Rechargeable Li Polymer/Approximately fi fteen hours following a full charge (Power Meter only approx. twenty hours)            |
| Power Supply / Charger        | Universal, US, UK, Continental Europe, and Australian Plugs Included  |
| Power Requirements            | 95-260 VAC, 50-60 Hz, 3 VA Max  |
| Operating Temp. Range         | -10 to 40 C   |
| Storage Temp. Range           | Equipment -10 to 60C - Battery-10 to 40 C   |
| Dimensions (with boot )       | 5.9" L x 3.9" W x 1.37" H (150mm L x 100mm W x 35mm H)  |
| Weight                        | 0.52 Kg   |
| Accessories Provided          | FC, ST, SC adaptors for both PM and LS, rubber boot, battery, Power supply/Charger, manual , USB Cable, PC application software |

TTI reserves the right to change specifications without notice

#### **Ordering Information**

| PM-1500       | Auto Wave Power Meter +5 dBm to - 77 dBm    | PM-1500C    | CATV Auto Wave Power Meter +25 dBm to<br>-57dBm |
|---------------|---|-------------|---|
| Loss Test Set |   |             | Light Source                                    |
| LTS-1500-813  | Loss Test Set with 850/1300nm Light Source  | LS-1500-813 | 850/1300nm Multi-Mode Light Source              |
| LTS-1500-3    | Loss Test Set with 1310nm Light Source      | LS-1500-3   | 1310nm Singlemode Light Source                  |
| LTS-1500-5    | Loss Test Set with 1550nm Light Source      | LS-1500-5   | 1550nm Singlemode Light Source                  |
| LTS-1500-35   | Loss Test Set with 1310/1550nm Light Source | LS-1500-35  | 1310/1550nm Singlemode Light Source             |
| LTS-1500-345  | Loss Test Set with 1310/1490/1550nm LS      | LS-1500-345 | 1310/1490/1550nm Singlemode LS                  |


For Loss Test Set, add a "C" for CATV version. Ex: LTS-1500C-3



Fiber

## FTE-4000 Variable **Optical Attenuator**

- Up to 80 dB Attenuation
- · Built in Level Control
- Typical Insertion Loss <2dB</li>
- Remotely Program Sweep Settings
- · Adjustable step sizes
- USB PC Interface w/Remote Operation
- Absolute/Relative Attenuation Settings
- Calibrated at 1310/1550
- · Sealed Rugged Case
- Lowest Cost Hand Held VOA
- · 4" Color Display



Onboard help system As with all of our advanced test equipment the LTS has an onboard help feature.

Applications The FTE-4000 can assist in the testing of system budget compliance, balancing transmitter power and adjusting receiver attenuation settings.

Built-In Level Control The built in level control automatically adjusts for stable output power.

Sweep Mode The sweep mode can scan the attenuation across a desired level.

Rugged The FTE-4000 is manufactured in our rugged splash proof housing with a highly protective

#### **Specifications**

| -                    |  |
|----------------------|--|
| ATTENUATION RANGE    | FTE-4000-4 2 to 40dB FTE-4000-8 4 to 80dB  |
| WAVELENGTH RANGE     | 1310, 1550 nm  |
| RESOLUTION           | .01 dB   |
| UNCERTAINTY          | +/- 0.5 dB   |
| REPEATABILITY        | +/- 0.1 dB   |
| INSERTION LOSS       | <2 dB  |
| RETURN LOSS          | 50 dB  |
| MAX INPUT POWER      | 27 dBm   |
| GRAPHICAL DISPLAY    | 4 in Color TFT   |
| DIMENSIONS W/O BOOT  | 7.62" L x 3.88" W x 1.56" H<br>(194mm L x 99mm W x 40mm H)                                       |
| WEIGHT               | 1.6 lbs  |
| BATTERY              | Rechargeable NiMH - 6 hours operating time   |
| POWER                | 100-240 universal US, GB, EU, AU Mains   |
| ENVIRONMENTAL        | Operation -10°C to + 40°C  |
| ACCESSORIES INCLUDED | Universal power supply. FC and SC adaptors, Windows TM Compatible Software, USB Cable and Manual |

Specifi cation are Subject to Change Without Notice

## Optical Spectrum **Analyzer**

FTE8000




#### **Features**

- Up To 88 Channels on the ITU Grid
- 50 or 100 GHz DWDM Channel Spacing
- Pass/Fail Thresholds and Drift Statistics
- Fast Real Time with <1/2 second Update</li>
- · Bar Graph and Table Displays
- Auto Test Zooms in on Active Channels
- Rugged Case w/Impact Resistant Boot
- Solid State Optics-No Moving Parts
- Easy Operation with Help Mode
- Available in C, L or S Band
- 4" Color Display
- 8hr Battery Life
- Sealed Rugged Case
- Impact Resistant Boot
- Stores 1000 test
- · USB/PC and USB Flash ports

Terahertz Technologies introduces the next generation Handheld Mini OSA. The FTE-8000 Optical Spectrum Analyzer is the most rugged and affordable full featured Mini OSA in the market. It is designed for simple operation and is suited for field or lab use. The mini OSA is available in up to 88 channels on the ITU Grid, offers 50 or 100 GHz channel spacing and displays a full scan twice a second. The FTE-8000 offers high end features such as Power Tilt for DWDM channel equalization and Gain Tilt to adjust EDFA gain fl atness. With its one button AutoTest feature, and a full set of selectable scale limits and thresholds, the FTE-8000 makes zeroing in on channel measurements easy.

For fl exibility the channel numbers are selected in wavelength or frequency and the information is displayed in graph or table mode on the 4 inch, high brightness color LCD. The unit allows users to set Pass/Fail thresholds and can store up to 1000 tests that can be downloaded via the USB PC or USB fl ash ports and documented with the included certification software for fast, easy reporting. The onboard Help system guides new users through operation and assists in parameter settings. The FTE- 8000 is housed in a rugged metal enclosure with a robust protective boot.


#### **Graph View**



The FTE-8000 graph display can be confi gured to optimize the view of test information.

The user can zoom in on specific channels, mark the display area in which channels meet power criteria and even limit the number of overall channels viewed.

#### **Table View**



In the table view, the FTE-8000 displays failed channels in red and when a channel is highlighted, statistical information is displayed including the minimum, maximum and average power levels.

Wavelength Range

**Wavelength Accuracy** 

**Channel Power Range** 

**Optical Rejection Ratio** 

**Channel Spacing** 

**Absolute Accuracy** 

**Readout Resolution** 

**Measurement Time** 

**Graphical Display** 

**Return Loss Optical Interface** 

**Dimensions** 

**Environmental** 

**Accessories Included** 

Display

Weight

**Battery** 

**Power** 

PDL

www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

FTE-8000Specifications

FTE-8000CWDM 1270-1610nm

50GHz, 100GHz or 20nm (CWDM)

±0.1nm

±1 dB

0.01dB

±0.15dB

>40dB

+10dBm to -50dBm

40dBc (@50GHz)

Universal UPC (FC/SC)

Bar Graph and Table View

7.75 x 4.5 x 2.25 inches

Operation -10°C to 50°C

Rechargeable NiMH - 8 hours operating time

Universal power supply with mains for US, UK, CE and AU.

Interchangeable FC and SC adapters, Window's™ compatible software,

100-240 universal US, GB, EU, AU Mains

USB cable, manual and rubber boot

< 1/2 Second

4 in Color TFT

FTE-8000S 1492-1528nm (200.9 THz - 196.2 THz)

FTE-8000C 1530-1561nm (196.0 THz - 192.0THz)

FTE-8000L 1570-1625nm (190.5 THz - 186.3 THz)

### **Tuneable Laser** Source

FTE6000

#### **Features**

- Selectable Step Size Down to 50 GHz
- · Selectable Start & Stop Channels
- · Settable in Wavelength or Frequency
- Settable Dwell Time
- · Available in C or L Band
- · Sealed Rugged Case with Impact Resistant Boot
- · USB PC Interface with Remote operation Capability
- Battery Operated or International Line Voltage
- Simple Operation with On-Line Help Mode
- · Lowest Cost Hand Held Tunable Laser Source
- · Interchangeable Fiber Optic Connectors
- · Up to 88 Channels on the ITU Grid
- Fast Turn-On
- · 4" Color Display
- · 4 hr Battery Life




The Terahertz Technologies FTE-6000 Hand Held Tuneable Laser Source (TLS) Is available in C and L Bands. The FTE-6000 is manufactured in our rugged splash proof housing with a highly protective boot. Our TLS displays in wavelength, frequency or ITU channel. The Tuneable Laser Source is a great match with our FTE-8000 (Optical Spectrum Analyzer) for installation, commissioning and trouble shooting of DWDM networks. If necessary, the supplied virtual instrument software may be used to operate the unit remotely.

The FTE-6000 offers a fast start up with minimal warm up required and provides very stable wavelength and power outputs. As with all of our Advanced tests equipment series, the FTE-6000 is affordable, easy to use and rugged. Ask about our kit offerings, such as the FTE-8600 Combo Kit.

#### Ideal for Installation, Maintenance and Upgrades of **DWDM Systems**

With the TTI FTE-6000 Tuneable Light Source, you can conduct a sweep of the ITU Grid by setting your beginning and ending wavelengths. You can also set your step size, power level, dwell time and whether you want the sweep to move up or down the scale. You can even set it to repeat the sweep.



### Fiber Optic **Video Link**

V-250

#### **Features**

- · Easy to Install and Use
- Low Cost
- AGC is Standard
- Eliminates Ground Loops
- · Distances up to 20 Km
- · NTSC, PAL and SECAM compatible
- · Available in MM and SM
- · LED Indicator of Video Signal






The V-250 is designed for transmitting high quality video in any standard format over much longer distances than are possible with coaxial cable. The plug and play design make this system simple to install and use, the builtin automatic gain control eliminates the need for adjustments by automatically compensating for varying cable lengths, degradation of splices and variations in video signal strength. The unit comes equipped with a bi-color LED that indicates the presence of video signals and proper operation of the units. This rugged, lowcost system is immune to the effects of radiated interference, high voltage differentials, water, ground loops, and the effects of hazardous environments.

The V-250 video transmission system consists of the VXT-250 Fiber Optic Transmitter, the VR-250 Fiber Optic Receiver and two 115/240 VAC power adapters. The system

is fully compatible with NTSC, SECAM, PAL and D2MAC video standards. Small in size, the VXT-250 mounts directly on the output BNC connector of the camera or video source. The V-250-850 operates at an optical wavelength of 850 nm. With its 16 dB link budget it can support transmission distances in excess of 5 km. If greater distances are required, the V-250-1300MM and V250-1300SM can be used for distances of 10 or 20 km.



www.toptical.com.tw 02-2346-1510 toptical@ms17.hinet.net

| Part Numbers |  |  |
|--------------|--|--|
| FTE-6000C    | C-Band Tuneable Laser Source                                       |  |
| FTE-6000L    | L-Band Tuneable Laser Source                                       |  |
| FTE-8600C    | C-Band Tuneable Laser Source with C Band Optical Spectrum Analyzer |  |
| FTE-8600L    | L-Band Tuneable Laser Source with L Band Optical Spectrum Analyzer |  |



**Dimensions Receiver** 


**Power Requirement** 

#### V-250 Specifi cations 10Hz - 10MHz (-3dB) **System Bandwidth** Input.Output Imdedance 75 Ohms **Norminal Input/Output Voltage** 1V p-p **Operating Wavelength** 850/1300nm **Optical Connectors** ST BNC **Signal Connectors** Link Budget (850/1300) 16/14 dB **Differential Gain** 2% Typical **Differential Phase** 2 Degrees Typical **Signal To Noise Ratio** 65dB Minimum 0 - 50 C **Operating Temperature Dimensions Transmitter** 1.5"Dia. x 1.5"L

4.5"L x 2.5"W x 1"H

120/240 VAC 50-60Hz

#### **Typical Installation**



| Model Selector |            |            |               |
|----------------|------------|------------|---------------|
| Part Number    | Wavelength | Cable      | Max. Distance |
| V250-850       | 850nm      | Multi-Mode | 5 km          |
| V250-1300MM    | 1300nm     | Multi-Mode | 10 km         |
| V250-1300SM    | 1310nm     | Singlemode | 20 km         |

# Visual Fault Locator

VFL-280

#### Features

- Universal 2.5 mm Adapter
- Modulated Mode for Easier Fault Locating
- Standard AA Batteries
- >100 Hour Battery Life
- · Multi-Mode and Singlemode Applications
- Compact Size



The VFL-280 Visual Fault Locator is an easy to use piece of equipment that allows the precise location of a breaks or severe micro bends in a fi ber or cable under test by visually checking your fi ber for leaks of visible light. In the same manner leaky splices or connectors within patch panels can be located and the VFL can assist in locating breaks within the dead zone of an OTDR. Visual fault locators make fi ber identifi cation easy in multi-fi ber cables.

The VFL-280 is rugged, lightweight and sized to fit in any tool kit. It is operates on 2 AA alkaline batteries and the unit has an over-rideable power saver feature that will power down the unit after 30 minutes. It is shipped with a Standard 2.5mm universal adapter. The internal ferrule is easily cleaned and the split sleeve is replaceable. The Unit is designed to be used on both Singlemode and Multi-mode fi bers.

| Specifi cations        |                          |  |  |
|------------------------|--------------------------|--|--|
| Output Power           | 1mW max                  |  |  |
| Wavelength             | 650 nm +/- 5nm           |  |  |
| Pulse Rate             | 6 Hz                     |  |  |
| Emission Indicator     | LED                      |  |  |
| Standard F/O Connector | Universal 2.5 mm Ferrule |  |  |
| Duty Cycle             | 50%                      |  |  |
| Battery                | 2 (AA) Alkaline          |  |  |
| Battery Life           | >100 hrs.                |  |  |
| Size                   | 4.0" L x 2.5" W x 1.1" D |  |  |
| Weight                 | 4.2 oz.                  |  |  |
| Operating Temperature  | -10 to 50 C              |  |  |
| Storage Temperature    | 30 to 60 C               |  |  |
| Auto Shut-Off          | 30 Min.                  |  |  |